



Tripoly International Group Limited

The following MTU4000 part numbers are our advantageous supply products, We provide original / genuine parts and high-quality aftermarket spare parts, are committed to fast delivery, and welcome inquiries. EMAIL: sales@diesel-cn.com

No.	Part Number	Designation	Series
1	5240200305	EXHAUST TURBOCHARGER	MTU 16V4000
2	5241870380	GASKET	MTU 16V4000
3	0005333080	O-RING FOR ONE	MTU 16V4000
4	5241420480	GASKET(5381420180)	MTU 16V4000
5	5381420180	GASKET(5241420480)	MTU 16V4000
6	700429015004	O-RING	MTU 16V4000
7	5244920181	SEALING RING	MTU 16V4000
8	5249900405	STUD	MTU 12V4000G21-G81
9	11506101	NUT	MTU 12V4000G21-G81
10	5241420152	SPACER WASHER	MTU 12V4000G21-G81
11	5240160319	SEALING RING SIZE 0	MTU 12V4000G21-G81
12	5240161580	GASKET FOR CYLIND	MTU 12V4000G21-G81
13	5240110062	THRUST WASHER	MTU 12V4000G21-G81
14	E0000352500	VIBRATION DAMPER	MTU 12V4000G21-G81
15	5240500344	THRUST BEARING FLANG	MTU 12V4000G21-G81
16	000933012051	SCREW	MTU 12V4000G21-G81
17	E5260701201	HP PUMP	MTU 12V4000G21-G81
18	8693000017	CONTROL BLOCK	MTU 12V4000G21-G81
19	0000160119	SEALING RING	MTU 12V4000G21-G81
20	R0010106951	INJECTOR(E0010106951)(X52407500024)	MTU 12V4000G21-G81
21	E0010106951	INJECTOR(R0010106951)(X52407500024)	MTU 12V4000G21-G81
22	X52407500024	INJECTOR(E0010106951)	MTU 12V4000G21-G81
23	5249902101	SCREW	MTU 12V4000G21-G81
24	8699970294	SEALING RING	MTU 12V4000G21-G81
25	700429024001	O-RING	MTU 12V4000G21-G81
26	700429140000	O-RING	MTU 12V4000G21-G81
27	700429063000	O-RING	MTU 12V4000G21-G81
28	700429083000	O-RING	MTU 12V4000G21-G81
29	700429085002	O-RING	MTU 12V4000G21-G81
30	700429100000	O-RING	MTU 12V4000G21-G81
31	700429100001	O-RING	MTU 12V4000G21-G81
32	5240111380	GASKET	MTU 12V4000G21-G81
33	5269970345	O-RING	MTU 12V4000G21-G81
34	700429018005	O-RING	MTU 12V4000G21-G81
35	5269870535	PROFILE RUBBER	MTU 12V4000G21-G81
36	700429070000	O-RING	MTU 12V4000G21-G81
37	700429075002	O-RING	MTU 12V4000G21-G81
38	700429033001	O-RING	MTU 12V4000G21-G81
39	5240110570	STUD	MTU 12V4000G21-G81
40	5240110172	NUT	MTU 12V4000G21-G81
41	5240510110	CAMSHAFT BEARING SIZE	MTU 12V4000G21-G81
42	5550110059	SEALING RING FOR CYLIN(5550110159)	MTU 12V4000G21-G81
43	5550110159	SEALING RING FOR CYLIN(5550110059)	MTU 12V4000G21-G81
44	5240150271	DRAIN PLUG	MTU 12V4000G21-G81

45	700429015000	O-RING	MTU 12V4000G21-G81
46	700429024000	O-RING	MTU 12V4000G21-G81
47	5240332630	CRANKSHAFT	MTU 12V4000G21-G81
48	0029923501	BUSHING	MTU 12V4000G21-G81
49	0219976547	RADIAL-LIP SHFT SEAL	MTU 12V4000G21-G81
50	700429290000	O-RING	MTU 12V4000G21-G81
51	0219976647	RADIAL-LIP SHFT SEAL	MTU 12V4000G21-G81
52	700429180000	O-RING	MTU 12V4000G21-G81
53	700429150000	O-RING	MTU 12V4000G21-G81
54	000472068000	SNAP RING	MTU 12V4000G21-G81
55	R5240105720	CYLINDER HEAD COMPLETE(5240105720)	MTU 12V4000G21-G81
56	5240105720	CYLINDER HEAD COMPLETE(R5240105720)	MTU 12V4000G21-G81
57	5240160321	GASKET	MTU 12V4000G21-G81
58	5241801819	OIL LINE	MTU 12V4000G21-G81
59	5240700933	HP LINE	MTU 12V4000G21-G81
60	23540939	SHELL SET	MTU 12V4000G21-G81
61	X00020290	NON-RETURN VALVE	MTU 12V4000G21-G81
62	X00020283	NON-RETURN VALVE	MTU 12V4000G21-G81
63	X00020271	NON-RETURN VALVE	MTU 12V4000G21-G81
64	5260701201	HP PUMP(E5260701201)	MTU 12V4000G21-G81
65	8591840001	GAITER	MTU 12V4000G21-G81
66	5260200805	EXHAUST TURBOCHARGER	MTU 12V4000G21-G81
67	0052031675	THERMAL ACTUATOR 45 °C	MTU 12V4000G21-G81
68	23523202	COOLANT PUMP HIGH-TEMP C(5272001501)	MTU 12V4000G21-G81
69	5272001501	COOLANT PUMP HIGH-TEMP C(23523202)	MTU 12V4000G21-G81
70	X52420300001	COOLANT PUMP LT CIRCUIT	MTU 12V4000
71	E5262000501	COOLANT PUMP(5262000901)	MTU 12V4000
72	5262000901	COOLANT PUMP(E5262000501)	MTU 12V4000
73	0010106951	INJECTOR(E0010106951)	MTU 12V4000
74	0180945802	AIR FILTER	MTU 12V4000
75	5241840101	OIL FILTER	MTU 12V4000
76	0020922101	EASY-CHANGE FILTER(0020922010)	MTU 12V4000
77	0020922010	EASY-CHANGE FILTER(0020922101)	MTU 12V4000
78	0000925005	FILTER ELEMENT	MTU 12V4000
79	700429132000	O-RING	MTU 12V331C92
80	5240114210	CYLINDER LINER SIZE 0(5240113410)	MTU 12V4000
81	5240113410	CYLINDER LINER SIZE 0(5240114210)	MTU 12V4000
82	5550110259	SEALING RING	MTU 12V4000
83	5249970020	COVER	MTU 12V4000
84	5240110159	CARBON SCRAPER RING	MTU 12V4000
85	007603014102	SEALING RING	MTU 12V4000
86	700429042000	O-RING	MTU 12V4000
87	700429055001	O-RING	MTU 12V4000
88	23524783	WASHER SEAL/WASHER SEAL	MTU 12V4000
89	5240111480	GASKET	MTU 12V4000
90	007603030101	DICHTRING	MTU 12V4000
91	23540714	HOSE	MTU 12V4000
92	05104958	CLAMP	MTU 12V4000
93	02419764	CLAMP	MTU 12V4000
94	5501871280	GASKET	MTU 12V4000
95	5241800155	SUCTION BASKET	MTU 12V4000
96	700429048000	O-RING	MTU 12V4000
97	700429040000	O-RING	MTU 12V4000
98	007603052101	SEALING RING	MTU 12V4000

99	007603038101	GASKET	MTU 12V4000
100	700429080001	O-RING	MTU 12V4000
101	5242030080	GASKET	MTU 12V4000
102	007603026104	SEALING RING	MTU 12V4000
103	0001800015	PRESS REDUCING VALVE	MTU 12V4000
104	5241880080	GASKET	MTU 12V4000
105	735221011000	O-RING	MTU 12V4000
106	5241880180	GASKET	MTU 12V4000
107	200625906237	GROOVED BALL BEARING	MTU 12V4000
108	5275420159	SEALING RING	MTU 12V4000
109	5271540014	CARBON BRUSH	MTU 12V4000
110	5275590671	GROUNDING EQUOPMT	MTU 12V4000
111	5260300701	CRANKSHAFT(E5260300701)	MTU 12V4000
112	E5260300701	CRANKSHAFT(5260300701)	MTU 12V4000
113	5240336101	CRANKSHAFT BEARING	MTU 12V4000
114	5240336602	CRANKSHAFT BEARING	MTU 12V4000
115	5240332508	CRANKSHAFT ALIGN BEARING	MTU 12V4000
116	700429420000	O-RING	MTU 12V4000
117	735073008000	PLUG	MTU 12V4000
118	X00008372	PISTON SKIRT	MTU 12V4000
119	5240301220/42	CONROD	MTU 12V4000
120	5240384110	CONROD BEARING UPPER HA	MTU 12V4000
121	5240383511	CONROD BEARING LOWER H	MTU 12V4000
122	5240530701	CYLINDER HEAD COMPLETE(5240530701)	MTU 12V4000
123	5240531101	INLET VALVE	MTU 12V4000
124	5240530905	EXHAUST VALE	MTU 12V4000
125	5240530122	VALVE SPRING INNER	MTU 12V4000
126	5240530120	VALVE SPRING OUTER	MTU 12V4000
127	5240530125	SPRING RETAINER	MTU 12V4000
128	0000530926	VALVE COLLET	MTU 12V4000
129	0000534335	VALVE ROTATOR	MTU 12V4000
130	700429039000	O-RING	MTU 12V4000
131	5240160153	SLEEVE	MTU 12V4000
132	5240530530	VALVE GUIDE(5240530830)	MTU 12V4000
133	5240530830	VALVE GUIDE(5240530530)	MTU 12V4000
134	5240161680	GASKET	MTU 12V4000
135	5249900701	SCREW	MTU 12V4000
136	5240160069	SCREW	MTU 12V4000
137	5240500930	PUSH ROD	MTU 12V4000
138	5240502335	SWING FOLL	MTU 12V4000
139	5240500833	ROCKER ARM	MTU 12V4000
140	000933010194	SCREW	MTU 12V4000
141	5240551106	VALVE BRIDGE	MTU 12V4000
142	000931016091	SCREW	MTU 12V4000
143	700521016200	WASHER	MTU 12V4000
144	5240160205	CYLINDER HEAD COVER	MTU 12V4000
145	23526402	BOLT	MTU 12V4000
146	5260701601	INJECTION PUMP	MTU 12V4000
147	700429130003	O-RING (X00011161)	MTU 12V4000
148	X00011161	O-RING (700429130003)	MTU 12V4000
149	23540850	CONTROL BLOCK CPL	MTU 12V4000
150	8699970295	SEALING RING	MTU 12V4000
151	5319972445	SEALING RING	MTU 12V4000
152	5319970345	SEALING RING	MTU 12V4000

153	5319972945	SEALING RING	MTU 12V4000
154	23540260	SEAL RING INJECTOR	MTU 12V4000
155	700429021001	O-RING	MTU 12V4000
156	23540449	PIPE	MTU 12V4000
157	23540110	PIPE	MTU 12V4000
158	5249970081	GROMMET	MTU 12V4000
159	0000786649	PRESS RELIEF VALVE	MTU 12V4000
160	0000787949	FLOW RESTRICT VALVE	MTU 12V4000
161	5240700833	HP LINE	MTU 12V4000
162	700429036001	O-RING	MTU 12V4000
163	5260910401	FUEL DELIVERY PUMP	MTU 12V4000
164	CA130210	HOSE ASM NO.06*21.0	MTU 12V4000
165	CA130180	HOSE ASM NO.06*21.8	MTU 12V4000
166	5244700164	FUEL LINE	MTU 12V4000
167	700429024002	O-RING	MTU 12V4000
168	5244700107	VALVE	MTU 12V4000
169	5244700007	VALVE	MTU 12V4000
170	05148007	VALVE	MTU 12V4000
171	700429037002	O-RING	MTU 12V4000
172	5249970745	O-RING	MTU 12V4000
173	5240902976	FUEL LINE	MTU 12V4000
174	5249970845	O-RING	MTU 12V4000
175	23540103	FUEL PIPELINE	MTU 12V4000
176	5269870235	PROFILE RUBBER	MTU 12V4000
177	5269970045	O-RING	MTU 12V4000
178	5240980680	GASKET	MTU 12V4000
179	23540072	O-RING	MTU 12V4000
180	5241420580	GASKET	MTU 12V4000
181	0001427057	LAMELLAR RING	MTU 12V4000
182	5260201005	EXHAUST TURBOCHARGER	MTU 12V4000
183	23517076	GASKET(5241420480)	MTU 12V4000
184	01115615	SWITCH STARTING SOL.	MTU 12V4000
185	0021803401	OIL PUMP	MTU 12V4000
186	700429058001	O-RING	MTU 12V4000
187	700429065000	O-RING	MTU 12V4000
188	5249930301	SPRING	MTU 12V4000
189	23526690	VALVE	MTU 12V4000
190	5249970545	SEALING RING	MTU 12V4000
191	8691840019	VALVE	MTU 12V4000
192	23540304	GASKET KIT	MTU 12V4000
193	5241880226	COOLER CORE	MTU 12V4000
194	5249970245	O-RING	MTU 12V4000
195	5249970040	SEALING WASHER	MTU 12V4000
196	5241801743	OIL NOZZLE	MTU 12V4000
197	5241870026	SCREW-FITTING UNION(5249972172)	MTU 12V4000
198	5249972172	SCREW-FITTING UNION(5241870026)	MTU 12V4000
199	5241802320	PIPE LEFT	MTU 12V4000
200	5241802420	PIPE RIGHT	MTU 12V4000
201	8695860598	REPAIR KIT	MTU 12V4000
202	8695860599	REPAIR KIT	MTU 12V4000
203	700429120002	O-RING	MTU 12V4000
204	700429058002	O-RING	MTU 12V4000
205	8492010001	ROTARY SEAL(8492000005)	MTU 12V4000
206	8492000005	ROTARY SEAL(8492010001)	MTU 12V4000

207	700489060000	GASKET	MTU 12V4000
208	700429072000	O-RING	MTU 12V4000
209	05132155	SEAL RING(5132155)	MTU 12V4000
210	5132155	SEAL RING(05132155)	MTU 12V4000
211	5242031152	RESTRICTOR	MTU 12V4000
212	0052033575	THERMOSTAT	MTU 12V4000
213	5242030075	THERMAL ACTUATOR(0052031675)	MTU 12V4000
214	5242030680	GASKET	MTU 12V4000
215	007603022102	GASKET	MTU 12V4000
216	5241500450	ALTERNATOR	MTU 12V4000
217	23540876	V-BELT TENSIONER	MTU 12V4000
218	23540397	RIBBED BELT	MTU 12V4000
219	5249970492	V-BELT	MTU 12V4000
220	5245400097	SOLENOID VALVE	MTU 12V4000
221	CP130367	HOSE ASM NO 12*40.7	MTU 12V4000
222	CK130153	HOSE	MTU 12V4000
223	CK110160	HOSE ASM NO 05*18.7	MTU 12V4000
224	CB110300	HOSE ASM NO 08*34.0	MTU 12V4000
225	5319972045	SEALING RING	MTU 12V4000
226	5319971045	SEALING RING	MTU 12V4000
227	23512423	JOURNAL(5242240020)	MTU 12V4000
228	5242240020	JOURNAL(23512423)	MTU 12V4000
229	5242520006	THRUST WASHER	MTU 12V4000
230	23540167	HARNESS,A-BANK 12V	MTU 12V4000
231	23540166	HARNESS,A-BANK 12V	MTU 12V4000
232	0005355630	TEMPERATURE SENSOR	MTU 12V4000
233	23540503	SENSOR HIGH PRESSURE(23526036)(0035351331)	MTU 12V4000
234	23526036	SENSOR HIGH PRESSURE(23540503)(0035351331)	MTU 12V4000
235	0035351331	SENSOR PRESSURE	MTU 12V4000
236	0055353831	PRESSURE SENSOR	MTU 12V4000
237	0055353731	PRESSURE SENSOR	MTU 12V4000
238	0005352233	SPEED SENSOR	MTU 12V4000
239	000912018008	SCREW	MTU 12V4000
240	23540298	INDICATOR	MTU 12V4000
241	0000181802	COVER	MTU 12V4000
242	000931010142	SCREW	MTU 12V4000
243	000931010105	SCREW	MTU 12V4000
244	000931012176	SCREW	MTU 12V4000
245	000912010038	SCREW	MTU 12V4000
246	000931010315	SCREW	MTU 12V4000
247	007603016105	SEALING RING	MTU 12V4000
248	304017008081	SCREW	MTU 12V4000
249	304017008076	SCREW	MTU 12V4000
250	000931012215	SCREW	MTU 12V4000
251	000933012079	SCREW	MTU 12V4000
252	000933012059	SCREW	MTU 12V4000
253	0029922401	BUSHING	MTU 12V4000
254	000000003020	SCREW	MTU 12V4000
255	000000003479	SCREW	MTU 12V4000
256	5550160633	COVER	MTU 12V4000
257	5800160033	COVER	MTU 12V4000
258	5240160233	COVER	MTU 12V4000
259	735073010001	PLUG	MTU 12V4000
260	0000910124	LINK	MTU 12V4000

261	000933008204	SCREW	MTU 12V4000
262	11509513	SCREW	MTU 12V4000
263	11509512	SCREW	MTU 12V4000
264	08929357	SCREW	MTU 12V4000
265	000933010095	SCREW	MTU 12V4000
266	11504516	SCREW	MTU 12V4000
267	0080375819	RECTANGLR-SECT RING	MTU 12V4000
268	0120370819	TAPER FACE COMP RING	MTU 12V4000
269	23526437	RING ASSY.OIL CONTR	MTU 12V4000
270	5261420704	EXHAUST PIPE	MTU 12V4000
271	5261420504	EXHAUST PIPE	MTU 12V4000
272	5261420604	EXHAUST PIPE	MTU 12V4000
273	0000352500	VIBRATION DAMPER(R0000352500)	MTU 12V4000
274	R0000352500	VIBRATION DAMPER(0000352500)	MTU 12V4000
275	F6784183	PULLER FOR INJECTOR	MTU 12V4000
276	F30377769	PULLER	MTU 12V4000
277	F6557991	PULLER	MTU 12V4000
278	F30377634	SOCKET ADAPTER	MTU 12V4000
279	50545	SEALING PASTE	MTU 12V4000
280	40031	SURFACE SEALANT	MTU 12V4000
281	40041	ASSEMBLY PRODUCTS	MTU 12V4000
282	40317	ASSEMBLY PRODUCTS	MTU 12V4000
283	50568	METALLIC FILLER	MTU 12V4000
284	40083	SCREW LOCKING DEVICE	MTU 12V4000
285	50155	SEALING TAPE	MTU 12V4000
286	50207	ADHESIVE	MTU 12V4000
287	40156	SEALANT	MTU 12V4000
288	X52404100028	SET RING	MTU 16V4000M70
289	C0010106951	CORE DEPOSIT	MTU 16V4000M70
290	5110208909/33	EXHAUST TURBOCHARGER LEFT(5110208909)	MTU 16V4000M70
291	5110208909	EXHAUST TURBOCHARGER LEFT(5110208909/33)	MTU 16V4000M70
292	5110209009/33	EXHAUST TURBOCHARGER RIGHT	MTU 16V4000M70
293	5260980520	INTERCOOLER LEFT	MTU 16V4000M70
294	5260980420	INTERCOOLER RIGHT	MTU 16V4000M70
295	0001880846	PLATE	MTU 16V4000M70
296	0001880946	FIRST PLATE	MTU 16V4000M70
297	0001881546	END PLATE	MTU 16V4000M70
298	5272002601	COOLANT PUMP HIGH-TEMP C(X52620200081)	MTU 16V4000M70
299	X52620200081	COOLANT PUMP HIGH-TEMP C(5272002601)	MTU 16V4000M70
300	0002033246	PLATE"A"VERSION	MTU 16V4000M70
301	0002033346	PLATE"B"VERSION	MTU 16V4000M70
302	0002033746	END PLATE	MTU 16V4000M70
303	0002034946	FIRST PLATE	MTU 16V4000M70
304	0002036346	END PLATE	MTU 16V4000M70
305	0002036446	FIRST PLATE	MTU 16V4000M70
306	5272001101	SEAWATER PUMP(X00012174)	MTU 16V4000M70
307	X00012174	SEAWATER PUMP(5272001101)	MTU 16V4000M70
308	0000925105	FILTER ELEMENT	MTU 16V4000M40
309	X00009628	COVERFOR SOLAS	MTU 16V4000M40
310	0180944502	PREFILTER	MTU 16V4000M40
311	0000911128	DIAPHRAGM	MTU 16V4000M40
312	5410180233	MEMBRANE	MTU 16V4000M40
313	5410100080	INSERT OIL SEPARATOR (5410100163)	MTU 16V4000M40
314	5410100163	INSERT OIL SEPARATOR (5410100080)	MTU 16V4000M40

315	000180680	GASKET	MTU 16V4000M40
316	700429060002	ORING 60X4 MM	MTU16 V 4000 M 90
317	5240980680	EMME MANIFOLD CONTASI	MTU16 V 4000 M 90
318	700429140000	ORING	MTU16 V 4000 M 90
319	5240160319	SEALING RING	MTU16 V 4000 M 90
320	700429039000	ORING	MTU16 V 4000 M 90
321	5240161580	GASKET	MTU16 V 4000 M 90
322	700429037000	ORING 37.7X3.53 MM	MTU16 V 4000 M 90
323	0020921901	EASY CHANGE FILTRE	MTU16 V 4000 M 90
324	0052031875	THERMAL ACTUATOR	MTU16 V 4000 M 90
325	0002034480	SEALING RING	MTU16 V 4000 M 90
326	700429 083000	ORING 83X5 MM	MTU16 V 4000 M 90
327	700429070000	ORING 70X5 MM	MTU16 V 4000 M 90
328	5240111380	GASKET	MTU16 V 4000 M 90
329	700429095004	ORING	MTU16 V 4000 M 90
330	0259972048	ORING	MTU16 V 4000 M 90
331	700429160000	ORING 16X5 MM	MTU16 V 4000 M 90
332	0299976748	SEALING RING	MTU16 V 4000 M 90
333	700429244000	ORING 244X4	MTU16 V 4000 M 90
334	700429075001	ORING 75X5 MM	MTU16 V 4000 M 90
335	700429023002	ORING	MTU16 V 4000 M 90
336	700429028005	ORING	MTU16 V 4000 M 90
337	5501871180	GASKET	MTU16 V 4000 M 90
338	700429027001	ORING 27X5	MTU16 V 4000 M 90
339	700429032003	ORING 32X4	MTU16 V 4000 M 90
340	700429100000	ORING	MTU16 V 4000 M 90
341	700429100001	ORING	MTU16 V 4000 M 90
342	0001501327	LU KUPPLUNG	MTU16 V 4000 M 90
343	700429192000	ORING	MTU16 V 4000 M 90
344	700429130003	ORING 130X5 MM	MTU16 V 4000 M 90
345	5249970545 700429122001	SEALING RING	MTU16 V 4000 M 90
346	5110804320	THURBINE WHEEL	MTU16 V 4000 M 90
347	5110850960	PISTON RING	MTU16 V 4000 M 90
348	5119940041	SNAP RING	MTU16 V 4000 M 90
349	X00031833	BEARING BUSHING	MTU16 V 4000 M 90
350	5110250052	WASHER	MTU16 V 4000 M 90
351	700429185001	ORING 185X3 MM	MTU16 V 4000 M 90
352	700429011002	ORING 11X3 MM	MTU16 V 4000 M 90
353	5110200278	VALVE	MTU16 V 4000 M 90
354	0239978348	ORING 288X4 MM.	MTU16 V 4000 M 90
355	5110200612	THRUST BEARING	MTU16 V 4000 M 90
356	X00010428	WASHER	MTU16 V 4000 M 90
357	5100850060	PISTON RING	MTU16 V 4000 M 90
358	700429105001	ORING 105X3.5 MM	MTU16 V 4000 M 90
359	5110250702	COMPRESOR WHEEL	MTU16 V 4000 M 90
360	5110250376	WASHER	MTU16 V 4000 M 90
361	5205301471	NUT	MTU16 V 4000 M 90
362	234110178000	PISTON RING	MTU16 V 4000 M 90
363	5591420451	RING ROTOTING	MTU16 V 4000 M 90
364	5272010505	PUMP SHAFT	MTU16 V 4000 M 90
365	5272040506	IMPELLER	MTU16 V 4000 M 90
366	0012010119	ROTARY SEAL	MTU16 V 4000 M 90
367	000472080000	SNAP RING	MTU16 V 4000 M 90

368	700386048001	SEALING RING	MTU16 V 4000 M 90
369	700429135000	ORING 135X5 MM	MTU16 V 4000 M 90
370	0039978648	ROTARY SEAL	MTU16 V 4000 M 90
371	X00008647 X52620200081	COOLANT PUMP	MTU16 V 4000 M 90
372	7603014102 007603014102	SEALING RING	MTU16 V 4000 M 90
373	5279970345 X00038945	ORING	MTU16 V 4000 M 90
374	700429018005	ORING 18X4 MM	MTU16 V 4000 M 90
375	E 0010106951	INJEKTOR KOMPLE (384710)	MTU16 V 4000 M 90
376	000471032000	SNAP RING	MTU16 V 4000 M 90
377	8699970397	SELALING RING	MTU16 V 4000 M 90
378	0049979947	SHAFT SEAL	MTU16 V 4000 M 90
379	8692040020	GAITER	MTU16 V 4000 M 90
380	8692040010	THURST RING	MTU16 V 4000 M 90
381	700429057000	ORING 57X3,5 MM	MTU16 V 4000 M 90
382	5552040580	GASKET	MTU16 V 4000 M 90
383	5502040906	IMPELLER	MTU16 V 4000 M 90
384	8691540076	REGULATOR	MTU16 V 4000 M 90
385	8691540085	THYRISTOR	MTU16 V 4000 M 90
386	8691510096	CARBON BRUSH	MTU16 V 4000 M 90
387	0035353931	PRESSURE SENSOR(X00038945)	MTU16 V 4000 M 90
388	X00038945	PRESSURE SENSOR(0035353931)	MTU16 V 4000 M 90
389	8695860486	PARTS KIT	MTU16 V 4000 M 90
390	2004115013	EXCITION WINDING	MTU16 V 4000 M 90
391	8691520004	ENGAGEMENT RELAY	MTU16 V 4000 M 90
392	8691520002	ENGAGEMENT RELAY	MTU16 V 4000 M 90
393	8692500086	FREEWHEEL	MTU16 V 4000 M 90
394	8695860484	PARTS KIT	MTU16 V 4000 M 90
395	8691510084	BRUSH HOLDER	MTU16 V 4000 M 90
396	2001933005	LEVER	MTU16 V 4000 M 90
397	8699900006	COUNTERSUNK HD SCR	MTU16 V 4000 M 90
398	0001806565	OIL COOLER	MTU 20V4000
399	F65 536 58	Angle-Of-Rot Jig	MTU4000
400	J-43 432	Injector Tube Clean	MTU4000
401	T80 089 09 44	Bracket	MTU4000
402	B80 146 887	Pump 0-3500bar	MTU4000
403	F67 878 80	Installation Jig	MTU4000
404	F67 894 33	Puller	MTU4000
405	F30 379 021	Extraction Pliers	MTU4000
406	F65 536 35	Assembly Jig	MTU4000
407	F65 571 21	Assembly Sleeve	MTU4000
408	F65 571 90	Ejection Device	MTU4000
409	B80 096 717	Lukas Press	MTU4000
410	B80 146 411	Adapter	MTU4000
411	F65 579 35	Tool Set	MTU4000
412	F65 571 86	Hydr Tensioner	MTU4000
413	Y43 419 47	Measuring Device	MTU4000
414	B80 146 524	Distributor	MTU4000
415	B80 144 838	Distributor	MTU4000
416	F65 579 36	Tool Set	MTU4000
417	B80 144 827	High Pressure Hose	MTU4000
418	B80 144 839	Hand Pump 3000HT	MTU4000
419	B80 144 960	High Pressure Pipe	MTU4000

420	F67 825 66	Extracting Fixture	MTU4000
421	T80 091 025	Lifing Jig	MTU4000
422	F01 401 74	Installation/Remove Jig	MTU4000
423	B80 004 007	Hex Nut	MTU4000
424	B80 144 155	Hydraulic Nut	MTU4000
425	F65 557 27	Draw Spindle	MTU4000
426	F67 805 92	Thrust Bush	MTU4000
427	F30 377 893	Installation/Remove Jig	MTU4000
428	F01 401 56	Installation/Remove Jig	MTU4000
429	B80 144 139	Hydraulic Nut	MTU4000
430	F65 557 34	Bushing	MTU4000
431	F65 571 44	Feed Shaft	MTU4000
432	F65 571 45	Thrust Bush	MTU4000
433	F67 805 43	Spacer	MTU4000
434	F67 805 55	Thrust Bush	MTU4000
435	F67 820 17	Tension Splindle	MTU4000
436	F01 404 40	Installation/Remove Jig	MTU4000
437	B80 098 529	Hex Nut	MTU4000
438	B80 146 622	Hydraulic Nut	MTU4000
439	0000171160	SEALING SEAL	MTU12V 4000G61
440	X00040714	CONROD BEARING SIZE 0-0	MTU12V 4000G61
441	5319970745	SEALING SEAL	MTU12V 4000G61
442	5241420780	GASKET	MTU12V 4000G61
443	0001426157	SEALING SEAL	MTU12V 4000G61
444	X00027830	CYLINDER LINER SIZE 0	MTU12V 4000G23
445	X00004135	GASKET	MTU12V 4000G23
446	700429024004	O-RING	MTU12V 4000G23
447	XP52699100029	O-RING	MTU12V 4000G23
448	X00009806	RECTANGLR-SECT RING	MTU12V 4000G23
449	0090375019	TAPER FACE COMP RING	MTU12V 4000G23
450	0120373618	OIL CONTROL RING	MTU12V 4000G23
451	X52407500004	INJECTOR	MTU12V 4000G23
452	0289976148	O-RING	MTU12V 4000G23
453	5249970090	CLAMP	MTU12V 4000G23
454	X00009917	GASKET	MTU12V 4000G23
455	700429192000	O-RING(700429198000)	MTU12V 4000G23
456	700429198000	O-RING(700429192000)	MTU12V 4000G23
457	700429256000	O-RING	MTU12V 4000G23
458	700429038003	O-RING	MTU12V 4000G23
459	5240530805	EXHAUST VALVE	MTU12V 4000G23
460	X00025995	INLET VALVE	MTU12V 4000G23
461	700429010004	O-RING	MTU12V 4000G23
462	000000000681	CLAMP	MTU12V 4000G23
463	5240110259	SCRAPER RING	MTU12V 4000G23
464	X52408200016	BANJO UNION	MTU12V 4000G23
465	0009973375	SINTERED FLTR	MTU12V 4000G23
466	0001424957	RING EXH MANIF	MTU12V 4000G23
467	X00026775	LEVEL MONITOR(X00E50205974)	MTU12V 4000G23
468	X00E50205974	LEVEL MONITOR(X00026775)	MTU12V 4000G23
469	5015300536	CONNECTING CABLE W/	MTU12V 4000G23
470	X00028443	ELBOW	MTU12V 4000G23
471	5240981739	RETAINER(5240982639)	MTU12V 4000G23
472	5240982639	RETAINER(5240981739)	MTU12V 4000G23
473	5280300417	PISTON	MTU20V 4000G62

474	5240370120	PISTON PIN	MTU20V 4000G62
475	0090373319	KEYSTON COMPR RING	MTU20V 4000G62
476	5240382550	CONROD BUSHING SIZE 0	MTU20V 4000G62
477	5249970192	V-BELT	MTU20V 4000G62
478	5240334901	CRANKSHAFT BEARIN(5240336101)	MTU20V 4000G62
479	5240335602	CRANKSHAFT BEARI	MTU20V 4000G62
480	5289870035	PROFILE RUBBER	MTU20V 4000G62
481	E5270700401	HP PUMP	MTU20V 4000G62
482	CX52807300008	CORE DESPOSIT FOR ITEM 014	MTU20V 4000G62
483	5500531231	VALVE SEAT INSERTINLET	MTU2000(3-11) 4000(12-30)
484	5410160121	GASKET	MTU2000(3-11) 4000(12-30)
485	8690920028	ELEMENT FILTER(8690920029)	MTU2000(3-11) 4000(12-30)
486	8690920029	ELEMENT FILTER(8690920028)	MTU2000(3-11) 4000(12-30)
487	0001423657	DICHTRING,METALL(51987010082)	MTU2000(3-11) 4000(12-30)
488	51987010082	DICHTRING,METALL(0001423657)	MTU2000(3-11) 4000(12-30)
489	X52404200029	GASKET FOR CYLINDER (5240161580)(X52404200035)(X	MTU2000(3-11) 4000(12-30)
490	X52404200035	GASKET FOR CYLINDER (5240161580)(X52404200029)(X	MTU2000(3-11) 4000(12-30)
491	X52404200042	GASKET FOR CYLINDER (5240161580)(X52404200029)(X	MTU2000(3-11) 4000(12-30)
492	5240530301	INLET VALVE	MTU2000(3-11) 4000(12-30)
493	5240530305	EXHAUST VALVE	MTU2000(3-11) 4000(12-30)
494	700429060002	O-RING	MTU2000(3-11) 4000(12-30)
495	5279970045	O-RING	MTU2000(3-11) 4000(12-30)
496	5279970245	O-RING	MTU2000(3-11) 4000(12-30)
497	000931014019	BOLT HEX	MTU2000(3-11) 4000(12-30)
498	700429870000	O-RING	MTU 12V4000G61
499	5249970145	O-RING	MTU 12V4000G61
500	5241870580	GASKET	MTU 12V4000G61
501	700429108000	O-RING	MTU 12V4000G61
502	5272030080	GASKET	MTU 12V4000G61
503	8692030147	GASKET	MTU 12V4000G61
504	700429065002	O-RING	MTU 12V4000G61
505	0012012219	ROTARY SEAL	MTU 12V4000G61
506	700429135000	O-RING	MTU 12V4000G61
507	X00029933/1	GREASE HAKUFORM 30-10 (40317)(X00058060)(X0005	MTU 12V4000G61
508	40317	GREASE HAKUFORM 30-10 (X00029933/1)(X00058060)(	MTU 12V4000G61
509	0045358831	RESEEURE SENSOR	MTU12V4000
510	5240700146	PRESS RELIEF VALVE(X00026227)	MTU12V4000
511	X00026227	PRESS RELIEF VALVE(5240700146)	MTU12V4000
512	5351530228	PRESSURE SENSOR	MTU 12V 4000L61
513	5351530528	PRESSURE SENSOR	MTU 12V 4000L61
514	5351530028	TEMP.SENSOR	MTU 12V 4000L61
515	5119900051	HEX NUT	MTU 12V 4000L61
516	000007005115	DOWEL PIN	MTU 12V 4000L61
517	E5272001501	COOLANT PUMP (5272002201)	MTU16V4000G61
518	5272002201	COOLANT PUMP (E5272001501)	MTU16V4000G61
519	8690940003	CARTRIDGE	MTU16V4000R41
520	0002040791	FILTER ELEMENT 6753359190 S4000	MTU16V4000R41
521	0000184560	FILTER ELEMENT	MTU16V4000R41
522	X00011024	O-RING	MTU16V4000R41
523	X00011026	O-RING	MTU16V4000R41
524	0020107051	NOZZLE HOLDER COMPLETE	MTU16V4000R41
525	9060170860	SEALING RING	MTU16V4000R41
526	0159973692	V-BELT	MTU16V4000R41
527	5249970483	HOSE RUBBER	MTU16V4000R41

528	700368010001	SLEEVE RUBBER	MTU16V4000R41
529	5279970083	RUBBER SLEEVE	MTU16V4000R41
530	5240980082	HOSE FLUOROCARBON LINER CHARGE AIR CO	MTU16V4000R41
531	0052035375	THERMAL ACTUATOR	MTU16V4000R41
532	0052031575	THERMAL ACTUATOR	MTU16V4000R41
533	5241420057	SEALING RING	MTU16V4000R41
534	0012012519	ROTARY SEAL	MTU16V4000R41
535	X00023653	RUBBER SLEEVE	MTU16V4000R41
536	00001426357	SEALING RING	MTU16V4000R41
537	0001426357	SEALING RING	MTU16V4000R41
538	EX52407500024	INJECTOR	MTU 16V4000
539	5240900450	PUMP FUEL LOW PRESSURE 8.6 BAR	MTU 12V4000G61
540	5241500150	GEN CHRG 24V100A AC 30SI FLG MT	MTU 12V4000G61
541	5372200078	PLUG ASSY	MTU 12V4000G61
542	00002370912	BUFFER	MTU 12V4000G61
543	5509970972	SCREW-FITTING ELEMENT	MTU 12V4000G61
544	5611802527	OIL LINE	MTU 12V4000G61
545	0001844125	OIL FILTER ELEMENT(5501800016)	MTU 12V4000G61
546	5501800016	OIL FILTER ELEMENT(0001844125)	MTU 12V4000G61
547	5372000358	VENT PIPE	MTU 12V4000G61
548	5550703032	FUEL LINE(5550707335)	MTU 12V4000G61
549	5550707335	FUEL LINE(5550703032)	MTU 12V4000G61
550	5500210053	PIPE	MTU 12V4000G61
551	200933010001	BOLT HEX	MTU 12V4000G61
552	200931010001	BOLT HEX	MTU 12V4000G61
553	5501421153	SLEEVE	MTU 12V4000G61
554	5552340405	SHAFT	MTU 12V4000G61
555	8381880080	GASKET(8381880280)	MTU 12V4000G61
556	8381880280	GASKET(8381880080)	MTU 12V4000G61
557	5500980280	GASKET	MTU 12V4000G61
558	0002033580	RING SEALING	MTU 12V4000G61
559	0099972445	O-RING(700429004000)	MTU 12V4000G61
560	700429004000	O-RING(0099972445)	MTU 12V4000G61
561	000N13235/1	GASKET	MTU 12V4000G61
562	007603017102	WASHER A COP	MTU 12V4000G61
563	5500163120	GASKET	MTU 12V4000G61
564	5502033180	GASKET	MTU 12V4000G61
565	5511421480	GASKET(5511421880)	MTU 12V4000G61
566	5511421880	GASKET(5511421480)	MTU 12V4000G61
567	5532030580	GASKET(532031280)	MTU 12V4000G61
568	532031280	GASKET(5532030580)	MTU 12V4000G61
569	5050610680	GASKET(5050612480)	MTU 12V4000G61
570	5050612480	GASKET(5050610680)	MTU 12V4000G61
571	0059976447	SHAFT SEAL	MTU 12V4000G61
572	5501880280	GASKET(5551881280)	MTU 12V4000G61
573	5551881280	GASKET(5501880280)	MTU 12V4000G61
574	5510980580	GASKET(5510980980)	MTU 12V4000G61
575	5510980980	GASKET(5510980580)	MTU 12V4000G61
576	5050610851	RING	MTU 12V4000G61
577	5050611780	GASKET(5050612880)	MTU 12V4000G61
578	5050612880	GASKET(5050611780)	MTU 12V4000G61
579	0029970348	O-RING	MTU 12V4000G61
580	5372010239	FLANGE	MTU 12V4000G61
581	700325018100	CLAMP HALF TUBE	MTU 12V4000G61

582	5050620553	SLEEVE	MTU 12V4000G61
583	5501530228	TEMPERATURE MONIT	MTU 12V4000G61
584	5501530128	TEMPERATURE MONIT	MTU 12V4000G61
585	5501531828	TEMPERATURE MONIT	MTU 12V4000G61
586	5050610532	PISTON	MTU 12V4000G61
587	0005310088	INCANDESCENT LAMP(0005318988)	MTU 12V4000G61
588	0005318988	INCANDESCENT LAMP(0005310088)	MTU 12V4000G61
589	0001534325	GAUGE MEC	MTU 12V4000G61
590	0031530231	REMOTE-READ THERMOM	MTU 12V4000G61
591	5502041280	GASKET(5562031180)	MTU 12V4000G61
592	5562031180	GASKET(5502041280)	MTU 12V4000G61
593	0000186235	OIL SEPARATOR	MTU 16V4000
594	5240332730	CRANSHAFT BEARING DRIVING END	MTU 4000
595	3579973182	INTAKE HOSE	MTU 4000
596	4479975282	INTAKE HOSE	MTU 4000
597	X00043095	COMPENSATING RING	MTU 4000
598	23540758	AIR FILTER	MTU 4000
599	700429480000	O-RING	MTU 4000
600	700429200002	O-RING	MTU 4000
601	X00036618	DUST PROTECTION RING	MTU 4000
602	X00028069	PISTON	MTU 4000
603	X00040057/42	CONROD	MTU 4000
604	5260530029	VALVE GUIDE	MTU 4000
605	X00018636	ROCKER ARM	MTU 4000
606	5240550320	ADJUSTING SCREW	MTU 4000
607	5240500145	THRUST MEMBER	MTU 4000
608	5240550550	BUSHING	MTU 4000
609	000439016201	HEX NUT	MTU 4000
610	700429074000	O-RING	MTU 4000
611	5249900605	SCREW	MTU 4000
612	5249900705	SCREW	MTU 4000
613	X52610100023	EXCHAUST TURBO CHARGERS	MTU 4000
614	X00044065	RUBBER SLEEVE	MTU 4000
615	5240980281	HOSE	MTU 4000
616	5240980281	HOSE	MTU 4000
617	5241421280	GASKET	MTU 4000
618	700429042002	O-RING	MTU 4000
619	X00033644	OIL SPRAY NOZZLE	MTU 4000
620	8699970136	O-RING	MTU 4000
621	8699970137	SHAFT SEAL	MTU 4000
622	700429018004	O-RING	MTU 4000
623	5272010805	COOLANT PUMP SHAFT	MTU 4000
624	700429076000	O-RING	MTU 4000
625	700429072000	O-RING	MTU 4000
626	5502040780	GASKET(5502040980)	MTU12V4000
627	5502040980	GASKET(5502040780)	MTU12V4000
628	5502040380	GASKET(5502041080)	MTU12V4000
629	5502041080	GASKET(5502040380)	MTU12V4000
630	X52407500028	INJECTOR	MTU16V4000
631	0005356633	SPEED SENSOR	MTU12V4000
632	0005357533	SPEED SENSOR	MTU12V4000
633	0005357333	SPEED SENSOR	MTU12V4000
634	0025358531	PRESSURE SENSOR	MTU12V4000
635	0030918101/87	FUEL DELIVERY PUMP	MTU16V4000R41

636	X00008649	COOLANT PUMP LOW-TEMP CI	MTU16V4000R41
637	5240201605	EXHAUST TURBOCHARGER LEFT	MTU16V4000R41
638	5240201805	EXHAUST TURBOCHARGER RIGHT	MTU16V4000R41
639	X00025778	CYL HEAD	MTU16V4000R41
640	X00022943	HEAT EXCHANGER	MTU16V4000R41
641	0020922901/87	FUEL FILTER	MTU16V4000R41
642	735038010108	HOSE	MTU16V4000R41
643	700160000010	ELBOW 90 DEG KR 10	MTU16V4000R41
644	735214012000	UNION	MTU16V4000R41
645	5275305322	WIRING HARNESS TO INJECTOR	MTU16V4000R41
646	X00027933	MONITOR MOD	MTU16V4000R41
647	0035352231	PRESSURE SENSOR	MTU16V4000R41
648	0015359102	DIFF-PRESS MONITOR	MTU16V4000R41
649	X00E50200773	LEVEL SENSOR	MTU16V4000R41
650	0005357633	SPEED SENSOR	MTU16V4000R41
651	X00001910	STARTER	MTU16V4000R41
652	X00001906	STARTERRIGHT	MTU16V4000R41
653	8695860529	CARBON BRUSH KIT	MTU16V4000R41
654	E0010107351	INJECTOR	MTU 16V4000M50B
655	5241420280	GASKET	MTU 12V4000
656	5249970316	BUSHING THREADED	MTU 12V4000
657	000000000403	NUT ADEC	MTU 12V4000
658	000000003306	SPRING PIN	MTU 12V4000
659	000007010124	PIN DOWEL	MTU 12V4000
660	0000188035	CANISTER CYL BLOCK BREATHER	MTU 12V4000
661	X52407800004	FLOW RESTRICT VALVE	MTU 12V4000
662	000125006431	WASHER	MTU 12V4000
663	0001539620	SENSOR TURB SPEED VDO	MTU 12V4000
664	0001840161	RING SEALING	MTU 12V4000
665	000471080000	RING SNAP HV ZNPH R5F	MTU 12V4000
666	000472042000	RING SNAP	MTU 12V4000
667	000472048000	RING SNAP	MTU 12V4000
668	000472062000	RING SNAP	MTU 12V4000
669	X00031103	LEVEL MONITOR	MTU 12V4000
670	00005356733	SPEED SENSOR	MTU 12V4000
671	000835010061	STUD	MTU 12V4000
672	000908018002	PLUG	MTU 12V4000
673	000908020000	PLUG	MTU 12V4000
674	000912012011	BOLT HEX SOC HD	MTU 12V4000
675	000931016068	BOLT HEX	MTU 12V4000
676	000933010198	BOLT HEX	MTU 12V4000
677	000933020017	BOLT HEX	MTU 12V4000
678	000988020019	RING SHIM	MTU 12V4000
679	0009939226	DISHED WASHER	MTU 12V4000
680	001474006000	PIN GROOVED	MTU 12V4000
681	0021804101	OIL PUMP(0021803301)	MTU 12V4000
682	0021803301	OIL PUMP(0021804101)	MTU 12V4000
683	5260910301	FUEL DELIVERY PUMP	MTU 12V4000
684	5275350431	PRESSURE SENSOR	MTU 12V4000
685	E5260701001	HP PUMP	MTU 12V4000
686	007603006100	SEALING RING	MTU 12V4000
687	5261800720	TUBE ASM TURBO OIL RETURN A-BAN	MTU 12V4000
688	5261800820	TUBE ASM TURBO OIL RETURN LINE	MTU 12V4000
689	0259972148	RING SEALING	MTU 12V4000

690	05103185	PLUG	MTU 12V4000
691	05130995	GASKET	MTU 12V4000
692	09414465	RING	MTU 12V4000
693	200625906017	BEARING BALL GROOVED 6007J	MTU 12V4000
694	200988045000	RING SHIM	MTU 12V4000
695	205412410002	BEARING CYLINDRICAL ROLLER N	MTU 12V4000
696	20736010000	SPRING PIN	MTU 12V4000
697	23516101	GASKET	MTU 12V4000
698	23518117	ISOLATOR ASM	MTU 12V4000
699	23519175	SENSOR 1/4"OPTICAL	MTU 12V4000
700	271511035000	GASKET	MTU 12V4000
701	5110200309	EXHAUST TURBOCHARGER	MTU 12V4000
702	5240104570	BREATHER	MTU 12V4000
703	5240110040	RETAINER	MTU 12V4000
704	5240110440	FILLER PIECE STRIP	MTU 12V4000
705	5240302417	PISTON	MTU 12V4000
706	5240333501	BEARING MAIN/0-0/(5240336101)	MTU 12V4000
707	5240500932	VALVE BRIDGE	MTU 12V4000
708	5240502235	SWING FOLL.EXHAUST	MTU 12V4000
709	5240502135	ROCKER ARM INLET	MTU 12V4000
710	5240510351	SPACER RING HOLES	MTU 12V4000
711	5240500436	ROCKER SHAFT SUPPORT	MTU 12V4000
712	5240550322	SLIDE PIN	MTU 12V4000
713	5040550520	ADJUSTING SCREW(5240550720)	MTU 12V4000
714	5240550720	ADJUSTING SCREW(5240550322)	MTU 12V4000
715	5240704232	FUEL RETURN LINE	MTU 12V4000
716	5240704332	TUBE ASM	MTU 12V4000
717	5240705032	TUBE FUEL MONITOR HP PUMP A-BA	MTU 12V4000
718	5240705132	FUEL LINE	MTU 12V4000
719	5240705332	FUEL LINE	MTU 12V4000
720	5240780276	THRUST MEMBER(5240780724)	MTU 12V4000
721	5240780724	THRUST MEMBER(5240780276)	MTU 12V4000
722	5240781024	THRUST MEMBER	MTU 12V4000
723	5240781853	TUBE PLUG IN END ME	MTU 12V4000
724	5240780535	CLAMP INJECTOR HOLD-DOWN	MTU 12V4000
725	5240780768	CONNECTING PIECE	MTU 12V4000
726	5240782153	PLUG-IN PIPE END PCE	MTU 12V4000
727	5240910024	DRIVE ADAPTER LP FUEL PMP M12X1.5	MTU 12V4000
728	5241510151	RING SPACER	MTU 12V4000
729	5241510251	RING SPACER	MTU 12V4000
730	5241800015	VALVE ASM PRESSURE	MTU 12V4000
731	5241800020	PIPE	MTU 12V4000
732	5241800120	TUBE ASM	MTU 12V4000
733	5241801643	NOZZLE LUBE OIL SPRAY	MTU 12V4000
734	5242340035	GEAR OIL PUMP	MTU 12V4000
735	5244760024	CONNECTING PIECE	MTU 12V4000
736	5244760324	FITTING	MTU 12V4000
737	5249810025	BEARING ASM BALL NTN CORP	MTU 12V4000
738	5249870051	FLAP SEAL	MTU 12V4000
739	5249970345	O-RING	MTU 12V4000
740	5249970616	BUSHING THREADED	MTU 12V4000
741	524SK0789	AIR COOLANT TUBE	MTU 12V4000
742	524SK1004	SPACER 10MMX18MM L=18	MTU 12V4000
743	5260780690	RAIL FUEL HIGH PRESSURE COMMON	MTU 12V4000

744	5260900876	TUBE FUEL DBL	MTU 12V4000
745	5261420350	BUSHING BEARING	MTU 12V4000
746	5261420060	FLANGE SEALING	MTU 12V4000
747	5261420150	BUSHING BEARING(5261420450)	MTU 12V4000
748	5261420450	BUSHING BEARING(5261420150)	MTU 12V4000
749	5261420250	BEAING BUSHING	MTU 12V4000
750	X52420200011	PUMP ASM WTR HI TEMP CLG	MTU 12V4000
751	5269870735	SEAL RUBBER STRIP 4200.0	MTU 12V4000
752	5275300520	WIRING HARNESS FOR	MTU 12V4000
753	735210014000	PLUG	MTU 12V4000
754	5319974272	FITTING	MTU 12V4000
755	5319976572	FITTING	MTU 12V4000
756	5350980050	BUSHING	MTU 12V4000
757	5359930020	SPRING TORSION	MTU 12V4000
758	5361840001	FILTER ELEMENT OIL(5241800110)	MTU 12V4000
759	5551530250	SPACER BUSHING	MTU 12V4000
760	5569970974	FITTING TEE	MTU 12V4000
761	5590780341	STRAP COOLANT DRAIN LINE	MTU 12V4000
762	5801533240	RETAINER(8801500873)	MTU 12V4000
763	8801500873	RETAINER(5801533240)	MTU 12V4000
764	700354014003	ADAPTER BUSHING	MTU 12V4000
765	700368028014	SLEEVE RUBBER	MTU 12V4000
766	700368038007	SLEEVE RUBBER	MTU 12V4000
767	735080018202	CHECK VALVE	MTU 12V4000
768	735151010100	SPACER	MTU 12V4000
769	8379902540	WASHER	MTU 12V4000
770	8499970035	GASKET	MTU 12V4000
771	8599970023	SEALING RING	MTU 12V4000
772	8690660006	COIL	MTU 12V4000
773	8693000013	CONTROL BLOCK	MTU 12V4000
774	8695860559	REPAIR KIT	MTU 12V4000
775	8699970154	ADHESIVE	MTU 12V4000
776	8699970369	SEALING RING	MTU 12V4000
777	8699970483	SEALING RING	MTU 12V4000
778	900288018001	HOSE CLAMP	MTU 12V4000
779	800288049003	CLAMP	MTU 12V4000
780	900288254000	CLAMP	MTU 12V4000
781	915005016000	CONE SEALING 18	MTU 12V4000
782	915006006000	UNION	MTU 12V4000
783	915007032002	CONNECTOR 32/25	MTU 12V4000
784	735214028000	UNION	MTU 12V4000
785	915013016002	UNION	MTU 12V4000
786	X00026765	SEAL ROTARY WATER PUMP	MTU 16V4000/770
787	0049971341	RING RUBBER	MTU 16V4000/770
788	X52707300001	FUEL PUMP	MTU 4000
789	X59407500014	INJECTOR	MTU 4000
790	0035352931	PRESSURE SENSOR(X00E50207217)	MTU 4000
791	X00E50207217	PRESSURE SENSOR(0035352931)	MTU 4000
792	E0080965599	TURBOCHARGER NEW EXCHANGE	MTU4000
793	CORE	CORE DEPOSIT	MTU4000
794	R23526589	INJ ASM 4000 REMAN	MTU4000
795	5240700538	TUBE ASM(5260700238)	MTU4000
796	5240700238	TUBE ASM(5260700538)	MTU4000
797	X00038950	SENSOR, HI PRES RAIL	MTU4000

798	23524605	SENSOR(A-08)	MTU4000
799	R23540850	CTRL BLK ASM	MTU4000
800	5241420280	GASKET	MTU12V4000
801	5249970316	BUSHING THRE	MTU12V4000
802	403	NUT ADEC	MTU12V4000
803	3306	SPRING PIN	MTU12V4000
804	7010124	PIN DOWEL	MTU12V4000
805	188035	CANISTER CYL	MTU12V4000
806	125006431	WASHER	MTU12V4000
807	1840161	RING SEALING	MTU12V4000
808	471080000	RING SNAP HV	MTU12V4000
809	472042000	RING SNAP	MTU12V4000
810	472062000	RING SNAP	MTU12V4000
811	5356733	SPEED SENSOR	MTU12V4000
812	835010061	STUD	MTU12V4000
813	908018002	PLUG	MTU12V4000
814	908020000	PLUG	MTU12V4000
815	912012011	BOLT HEX SOC	MTU12V4000
816	931016068	BOLT HEX	MTU12V4000
817	933010198	BOLT HEX	MTU12V4000
818	933020017	BOLT HEX	MTU12V4000
819	988020019	RING SHIM	MTU12V4000
820	1474006000	PIN GROOVED	MTU12V4000
821	21804101	OIL PUMP	MTU12V4000
822	5260910301	FUEL DELIVER	MTU12V4000
823	5275350431	PRESSURE SEN	MTU12V4000
824	7603006100	SEALING RING	MTU12V4000
825	5261800720	TUBE ASM TUR	MTU12V4000
826	5261800820	TUBE ASM TUR	MTU12V4000
827	299976748	O-RING	MTU12V4000
828	5103185	PLUG	MTU12V4000
829	5130822	WASHER	MTU12V4000
830	5130995	GASKET	MTU12V4000
831	5132155	C--SEAL	MTU12V4000
832	9414465	RING	MTU12V4000
833	200625906017	BEARING BALL	MTU12V4000
834	200988045000	RING SHIM	MTU12V4000
835	205412410002	BEARING CYLI	MTU12V4000
836	207346010000	SPRING PIN	MTU12V4000
837	23503627	BEARING	MTU12V4000
838	23516101	GASKET	MTU12V4000
839	23518117	ISOLATOR ASM	MTU12V4000
840	23519175	SENSOR ASSY	MTU12V4000
841	23523312	BUSHING HEX	MTU12V4000
842	23550135	3A: SCREW PLUG	MTU12V4000
843	5240104570	BREATHER	MTU12V4000
844	5240110040	RETAINER	MTU12V4000
845	5240110440	FILLER PIECE	MTU12V4000
846	5240500932	VALVE BRIDGE	MTU12V4000
847	5240510351	SPACER RING	MTU12V4000
848	5240500436	ROCKER SHAFT	MTU12V4000
849	5240550322	SLIDE PIN	MTU12V4000
850	5240550520	ADJUSTING SC	MTU12V4000
851	5240704232	FUEL RETURN(23540810)	MTU12V4000

852	23540810	FUEL RETURN(5240704232)	MTU12V4000
853	5240704332	TUBE ASM	MTU12V4000
854	5240705032	TUBE FUEL MO	MTU12V4000
855	5240705132	FUEL LINE	MTU12V4000
856	5240705332	FUEL LINE	MTU12V4000
857	5240780276	SPACER HIGH	MTU12V4000
858	5240781024	THRUST MEMBE	MTU12V4000
859	5240781853	TUBE PLUG IN	MTU12V4000
860	5240780535	CLAMP INJECT	MTU12V4000
861	5240780768	CONNECTING P	MTU12V4000
862	5240782153	PLUG-IN PIPE	MTU12V4000
863	5240910024	DRIVE ADAPTE	MTU12V4000
864	5241510151	RING SPACER	MTU12V4000
865	5241510251	RING SPACER	MTU12V4000
866	5241800015	VALVE ASM PR	MTU12V4000
867	5241800020	PIPE	MTU12V4000
868	5241800120	TUBE ASM	MTU12V4000
869	5241801643	NOZZLE LUBE	MTU12V4000
870	5242340035	GEAR OIL PUM	MTU12V4000
871	5244760024	CONNECTING P	MTU12V4000
872	5244760324	FITTING	MTU12V4000
873	5249810025	BEARING ASM	MTU12V4000
874	5249970345	5249970745	MTU12V4000
875	5249970616	BUSHING THRE	MTU12V4000
876	5260900876	TUBE FUEL DB	MTU12V4000
877	5261420350	BUSHING BEAR	MTU12V4000
878	5261420060	FLANGE SEALI	MTU12V4000
879	5261420150	BEARING BUSH	MTU12V4000
880	5261420250	BEARING BUSH	MTU12V4000
881	5269870735	SEAL RUBBER	MTU12V4000
882	5275300520	WIRING HARNE	MTU12V4000
883	735210014000	PLUG	MTU12V4000
884	5319974272	FITTING	MTU12V4000
885	5319976572	FITTING	MTU12V4000
886	5350980050	BUSHING	MTU12V4000
887	5359930020	SPRING TORSI	MTU12V4000
888	5361840001	23526919	MTU12V4000
889	700354014003	ADAPTER BUSH	MTU12V4000
890	700368028014	SLEEVE RUBBE	MTU12V4000
891	700368038007	SLEEVE RUBBE	MTU12V4000
892	735080018202	CHECK VALVE	MTU12V4000
893	735151010100	SPACER	MTU12V4000
894	8379902540	WASHER	MTU12V4000
895	8499970035	GASKET	MTU12V4000
896	8695860559	REPAIR KIT	MTU12V4000
897	8699970483	SEALING RING	MTU12V4000
898	900288018001	HOSE CLAMP 1	MTU12V4000
899	900288049003	CLAMP	MTU12V4000
900	900288254000	CLAMP	MTU12V4000
901	915006006000	UNION	MTU12V4000
902	915007032002	CONNECTOR 32	MTU12V4000
903	735214028000	UNION	MTU12V4000
904	E5260200905	EXHAUST TURB	MTU16V4000
905	C5260200905	CORE DEPOSIT	MTU16V4000

906	5241420480	GASKET	MTU16V4000
907	CX52407500024	CORE DEPOSIT	MTU16V4000
908	X00019778	AIR STARTER	MTU12V4000M60
909	5240900850	FUEL DELIVERY PUMP	MTU12V4000M60
910	0012011619	COOLANT PUMP ROTARY SEAL	MTU12V4000M60
911	5240201205	COMPLETE NEW TURBOCHARGER	MTU 16V4000G81
912	5240201605	EXHAUST TURB	MTU4000PARTS
913	5240201805	EXHAUST TURB	MTU4000PARTS
914	735038010108	HOSE	MTU4000PARTS
915	700160000010	ELBOW 90 DEG	MTU4000PARTS
916	735214012000	UNION	MTU4000PARTS
917	5275305322	WIRING HARNE	MTU4000PARTS
918	5285303769	CONNECTION I	MTU4000PARTS
919	5285303869	CONNECTION I	MTU4000PARTS
920	5295308712	PLUG-IN BOAR	MTU4000PARTS
921	5295309312	PLUG-IN BOAR	MTU4000PARTS
922	5295306812/S0003	PLUG-IN BOAR	MTU4000PARTS
923	5295305912/S0003	PLUG-IN BOAR	MTU4000PARTS
924	5045307892	PLUG-IN BOAR	MTU4000PARTS
925	535A06791/1	CONTACTOR	MTU4000PARTS
926	35352231	PRESSURE SEN	MTU4000PARTS
927	15359102	DIFF-PRESS M	MTU4000PARTS
928	5357533	SPEED SENSOR	MTU4000PARTS
929	5357633	SPEED SENSOR	MTU4000PARTS
930	8695860529	CARBON BRUSH	MTU4000PARTS
931	5240500930	PUSHROD	MTU4000PARTS
932	5240160321	GASKET	MTU4000PARTS
933	5240900450	PUMP FUEL LO	MTU4000PARTS
934	910124	COUPLING FUE	MTU4000PARTS
935	700429037002	O-RING	MTU4000PARTS
936	700429042001	O-RING	MTU4000PARTS
937	700429024001	O-RING	MTU4000PARTS
938	700429180000	O-RING	MTU4000PARTS
939	5240900950	PUMP FUEL PR	MTU4000PARTS
940	700429021001	O-RING	MTU4000PARTS
941	160119	SEALING RING	MTU4000PARTS
942	11506101	M--NUT	MTU4000PARTS
943	5249900405	STUD	MTU4000PARTS
944	700429870000	O-RING	MTU4000PARTS
945	5240980082	HOSE FLUOROC	MTU4000PARTS
946	5249970245	SEAL O-RING	MTU4000PARTS
947	700429290000	O-RING	MTU4000PARTS
948	5249970040	GASKET OIL C	MTU4000PARTS
949	5249970145	SEAL RING	MTU4000PARTS
950	1812498	PUMP SEMI RO	MTU4000PARTS
951	5355103	LEVEL MONITO	MTU4000PARTS
952	45358831	PRESSURE SEN	MTU4000PARTS
953	35352531	PRESSURE SEN	MTU4000PARTS
954	35352731	PRESSURE SEN	MTU4000PARTS
955	5357333	SPEED SENSOR	MTU4000PARTS
956	5205304531	SENSOR	MTU4000PARTS
957	5356430	TEMPERATURE	MTU4000PARTS
958	700429256000	O-RING	MTU4000PARTS
959	23540432	FILTER 4 LIT	MTU4000PARTS

960	X00026196	SUPPORT	MTU4000PARTS
961	125010524	WASHER	MTU4000PARTS
962	700429045001	O-RING	MTU4000PARTS
963	X00034695	RESTRICTOR	MTU4000PARTS
964	700429120000	O-RING	MTU4000PARTS
965	X00038531	HOSE TURBO O	MTU4000PARTS
966	X00021075	TUBE ASM TUR	MTU4000PARTS
967	5241806620	TUBE ASM TUR	MTU4000PARTS
968	X00E50201022	ECS	MTU4000PARTS
969	5240530805	VALVE EXHAUS	MTU4000PARTS
970	5240530122	SPRING VALVE	MTU4000PARTS
971	5240530120	SPRING VALVE	MTU4000PARTS
972	5240530301	INLET VALVE	MTU4000PARTS
973	5240530305	EXHAUST VALV	MTU4000PARTS
974	5241840101	FILTER ELEME	MTU4000PARTS
975	C0010107351	Core Deposit	MTU4000PARTS
976	5319972945	O-RING	MTU4000PARTS
977	5319970745	SEALING RING	MTU4000PARTS
978	E8693000017	CONTROL BLK	MTU4000PARTS
979	C8693000017	Core Deposit	MTU4000PARTS
980	735080018200	VALVE CHECK	MTU4000PARTS
981	20921901	FILTER EASY	MTU4000PARTS
982	EX00019778	STARTER	MTU4000PARTS
983	CX00019778	Core Deposit	MTU4000PARTS
984	31845301	FILTER ELEME	MTU4000PARTS
985	5240900850	PUMP FUEL LO	MTU4000PARTS
986	5240708932	FUEL LINE	MTU4000PARTS
987	915001020003	NUT	MTU4000PARTS
988	915005016000	CONE SEALING	MTU4000PARTS
989	915001016004	NUT 16 M26X1	MTU4000PARTS
990	5240700146	PRESS RELIEF	MTU4000PARTS
991	EX59407500014	INJECTOR	MTU4000PARTS
992	CX59407500014	INJECTOR	MTU4000PARTS
993	EX52407500027	INJECTOR(EX52407500043)	MTU12V4000G43F
994	EX52407500043	INJECTOR(EX52407500027)	MTU12V4000G43F
995	CX52407500027	CORE DEPOSIT	MTU12V4000G43F
996	5279970345	SEAL STRIP	MTU16V4000M90
997	5279870435	SEAL OIL PAN	MTU16V4000M90
998	5240310733	SEALING CAP	MTU16V4000M90
999	8699970331	GASKET	MTU16V4000M90
1000	8690740388	COMPENSATING	MTU16V4000M90
1001	700429016003	O-RING	MTU16V4000M90
1002	735038025103	HOSE	MTU16V4000M90
1003	239978348	RING SEAL	MTU16V4000M90
1004	934008013	NUT HEX	MTU16V4000M90
1005	200931010002	BOLT HEX GAL	MTU16V4000M90
1006	8695860556	REPAIR KIT	MTU16V4000M90
1007	219975582	HOSE METAL 3	MTU16V4000M90
1008	2011363	COUNTERRING	MTU16V4000M90
1009	717115065101	WASHER	MTU16V4000M90
1010	2030851	GUIDE RING	MTU16V4000M90
1011	8499970065	GASKET	MTU16V4000M90
1012	8499970066	GASKET	MTU16V4000M90
1013	12377312	ISOLATOR 60	MTU16V4000M90

1014	5240540101	ROLLER TAPPE	MTU16V4000M90
1015	5240550320	BOLT ADJUSTI	MTU16V4000M90
1016	911790	PUMP	MTU16V4000M90
1017	X00E50200574/76	PLUG-IN BOAR	MTU16V4000M90
1018	5045300897/78	PLUG-IN BOAR	MTU16V4000M90
1019	5358960	THERMOCOUPLE	MTU16V4000M90
1020	5382235	TRACK-BALL	MTU16V4000M90
1021	X00022734	CONTROL LEVE	MTU16V4000M90
1022	X00E50202364	PRINTER	MTU16V4000M90
1023	X00026303(5265309912)	PLUG-IN BOAR	MTU2000 AND MTU4000
1024	X00E50202703(5045307497)	PLUG-IN BOAR	MTU2000 AND MTU4000
1025	X00018258(5295308912)	PLUG-IN BOAR	MTU2000 AND MTU4000
1026	5550600163	SPEED SENSOR	MTU2000 AND MTU4000
1027	0005318788	FLASHING LAM	MTU2000 AND MTU4000
1028	0015317686	FUSE	MTU2000 AND MTU4000
1029	5295308812	PLUG-IN BOAR	MTU2000 AND MTU4000
1030	5295300413/78(5295300413)	PLUG-IN BOAR	MTU2000 AND MTU4000
1031	EX52407500023	INJECTOR	MTU4000
1032	X52620300023	PUMP ASM WTR LOW TEMP CLG CIRCUIT	MTU 12V4000S
1033	X00004486	STARTER	MTU 12V4000S
1034	E5260701101	HP PUMP	MTU20V 8000M70 AND 16V4000
1035	X00021910	PREFILTER MADE OF FLEECE	MTU20V 8000M70 AND 16V4000
1036	5279970345	SEAL STRIP	MTU 16V4000M90
1037	700429012002	O-RING	MTU 16V4000M90
1038	5550110159	SEALING RING SET FOR CYLINDER LINER(5550110059)	MTU 16V4000M90
1039	700429020003	O-RING	MTU 16V4000M90
1040	5801750180	GASKET	MTU 16V4000M90
1041	5240332730	BEARING CRANKSHAFT MAIN PTO END	MTU 16V4000M90
1042	5849970440	RING SEALING	MTU 16V4000M90
1043	5410180233	DIAPHRAGM(5410180333)	MTU 16V4000M90
1044	5410180333	DIAPHRAGM(5410180233)	MTU 16V4000M90
1045	5200180035	OIL SEPARATOR(5410100080)	MTU 16V4000M90
1046	5360520080	GASKET(DDE08929299)	MTU 16V4000M90
1047	DDE08929299	GASKET(5360520080)	MTU 16V4000M90
1048	5240336101	BEARING MAIN/0-0/UP/RIL(5240334901)	MTU 16V4000M90
1049	5240333307	BEARING THRUST/0-0/LO/SPT/	MTU 16V4000M90
1050	5240310733	SEALING CAP HIPO	MTU 16V4000M90
1051	8699970331	GASKET	MTU 16V4000M90
1052	0120370618	OIL CONTROL RING	MTU 16V4000M90
1053	5240383710	CONROD BEARING SIZE 0-0	MTU 16V4000M90
1054	5240383911	CONROD BEARING LOWER HALF (5240382711)	MTU 16V4000M90
1055	5240382711	CONROD BEARING LOWER HALF(5240383911)	MTU 16V4000M90
1056	000125010524	WASHER	MTU 16V4000M90
1057	700327018000	GROMMET	MTU 16V4000M90
1058	8699970397	SEALING RING	MTU 16V4000M90
1059	8690740388	COMPENSATING WASHER	MTU 16V4000M90
1060	8690740074	LOCKING RING	MTU 16V4000M90
1061	700429016003	O-RING	MTU 16V4000M90
1062	735038025103	HOSE	MTU 16V4000M90
1063	8490910100	GASKET	MTU 16V4000M90
1064	5800780180	GASKET	MTU 16V4000M90
1065	700327010000	GROMMET	MTU 16V4000M90
1066	007603006108	WASHER A COP	MTU 16V4000M90
1067	735038012103	HOSE	MTU 16V4000M90

1068	8695860572	GASKET KIT(8699970254)	MTU 16V4000M90
1069	8699970254	GASKET KIT(8695860572)	MTU 16V4000M90
1070	700327006000	GROMMET	MTU 16V4000M90
1071	735038016100	HOSE	MTU 16V4000M90
1072	700429200002	O-RING	MTU 16V4000M90
1073	234110178000	RING SEAL G7 KI KA	MTU 16V4000M90
1074	700429185001	O-RING	MTU 16V4000M90
1075	5110850960	RING SEAL ASM	MTU 16V4000M90
1076	5110200612	THRUST BEARING	MTU 16V4000M90
1077	000934008013	NUT HEX	MTU 16V4000M90
1078	700429160000	O-RING	MTU 16V4000M90
1079	700327008000	GROMMET	MTU 16V4000M90
1080	700429016000	O-RING	MTU 16V4000M90
1081	700429009004	O-RING	MTU 16V4000M90
1082	700327012000	GROMMET	MTU 16V4000M90
1083	700429244000	O-RING	MTU 16V4000M90
1084	0005330280	O-RING(735221011000)	MTU 16V4000M90
1085	5591420451	RING SEALING	MTU 16V4000M90
1086	0000982218	CYLINDER ACTUATING	MTU 16V4000M90
1087	000933010093	BOLT HEX S2000/4000	MTU 16V4000M90
1088	200931010002	BOLT HEX GAL CU 5 BK	MTU 16V4000M90
1089	200433010500	WASHER	MTU 16V4000M90
1090	000000001684	HEX NUT(200934010000)	MTU 16V4000M90
1091	200934010000	HEX NUT(000000001684)	MTU 16V4000M90
1092	8695860556	REPAIR KIT	MTU 16V4000M90
1093	0219975582	HOSE METAL 32X500 M45X1.5	MTU 16V4000M90
1094	700429027001	O-RING	MTU 16V4000M90
1095	700429028005	O-RING	MTU 16V4000M90
1096	5501871180	GASKET(5501870880)	MTU 16V4000M90
1097	700327022000	GROMMET	MTU 16V4000M90
1098	007603014106	WASHER A COP	MTU 16V4000M90
1099	00760301402	WASHER A COP	MTU 16V4000M90
1100	007603026109	WASHER A COP	MTU 16V4000M90
1101	007603018104	WASHER A COP	MTU 16V4000M90
1102	200628103006	BEARING ANGULAR CONTACT ROLLER	MTU 16V4000M90
1103	705100502035	BEARING CYLINDER ROLLER	MTU 16V4000M90
1104	0002041316	ROTARY SEAL	MTU 16V4000M90
1105	0002011363	COUNTERRING	MTU 16V4000M90
1106	717115065101	WASHER	MTU 16V4000M90
1107	700429172000	O-RING	MTU 16V4000M90
1108	700429080002	O-RING	MTU 16V4000M90
1109	700429085000	O-RING	MTU 16V4000M90
1110	0002030851	GUIDE RING	MTU 16V4000M90
1111	8499970065	GASKET	MTU 16V4000M90
1112	8499970066	GASKET	MTU 16V4000M90
1113	0002035083	RUBBER BELLOWS	MTU 16V4000M90
1114	700429175001	O-RING	MTU 16V4000M90
1115	5552032880	GASKET	MTU 16V4000M90
1116	700429190001	O-RING	MTU 16V4000M90
1117	5552031780	GASKET	MTU 16V4000M90
1118	700368042004	SLEEVE RUBBER	MTU 16V4000M90
1119	000000000020	CLAMP(900288054005)	MTU 16V4000M90
1120	735038008103	HOSE	MTU 16V4000M90
1121	002377312	ISOLATOR 60 SH RD314B-11 MN60	MTU 16V4000M90

1122	700429530000	O-RING	MTU 16V4000M90
1123	8699970358	SEALING RING	MTU 16V4000M90
1124	40033	SEALANT PIPE THREAD LOCTITE 586	MTU 16V4000M90
1125	40093	JOINTED PRODUCT	MTU 16V4000M90
1126	40477	PASTE OPTIMOLY	MTU 16V4000M90
1127	50547	PASTE ULTRA THERM MTU	MTU 16V4000M90
1128	X00048307	RTV	MTU 16V4000M90
1129	X00008369	PISTON(5240303917)	MTU 16V4000M90
1130	5240303917	PISTON (X00008369)	MTU 16V4000M90
1131	E5240301120/42	CONROD ASM(5240301120/42)	MTU 16V4000M90
1132	5240301120/42	CONROD ASM (E5240301120/42)	MTU 16V4000M90
1133	5240380471	BOLT M20 1.50X103. LG 18 CONROD	MTU 16V4000M90
1134	5240104520	CYLINDER HEAD(5240103420)	MTU 16V4000M90
1135	5240103420	CYLINDER HEAD(5240104520)	MTU 16V4000M90
1136	5240540101	ROLLER TAPPET	MTU 16V4000M90
1137	5240500433	ARM ROCKER INTAKE	MTU 16V4000M90
1138	5240500434	ARM ROCKER EXHAUST	MTU 16V4000M90
1139	5240550320	BOLT ADJUSTING	MTU 16V4000M90
1140	000931010332	BOLT HEX	MTU 16V4000M90
1141	0000911790	PUMP	MTU 16V4000M90
1142	8690920043	BOLT S2000/S4000	MTU 16V4000M90
1143	5110804320	TURBINE WHEEL	MTU 16V4000M90
1144	5110250702	COMPRESSOR WHEEL	MTU 16V4000M90
1145	5205301471	NUT	MTU 16V4000M90
1146	5260981120	COOLER CHARGE AIR A-BANK LB(5260980020)	MTU 16V4000M90
1147	5260980020	COOLER CHARGE AIR A-BANK LB(5260981120)	MTU 16V4000M90
1148	5260981220	COOLER CHARGE AIR A-BANK LB(5260980120)	MTU 16V4000M90
1149	5260980120	COOLER CHARGE AIR A-BANK LB(5260981220)	MTU 16V4000M90
1150	0051513501	STARTER FOR COMPRESSED AIR(X00019778)	MTU 16V4000M90
1151	5272010707	IMPELLER	MTU 16V4000M90
1152	0005358960	THERMOCOUPLE	MTU 16V4000M90
1153	5275300720	WIRING HARNESS	MTU16V4000
1154	5275302922	WIRING HARNESS	MTU16V4000
1155	X00036123	COOLANT HOSE	MTU4000PARTS
1156	X00036124	COOLANT HOSE	MTU4000PARTS
1157	X00003523	HOSE INTAKE	MTU4000PARTS
1158	X52701800011	HOSE INTAKE	MTU4000PARTS
1159	EX59610100228	EXHAUST TURBOCHARGER	MTU20V4000
1160	EX59610100229	EXHAUST TURBOCHARGER	MTU20V4000
1161	5249950059	STRAP	MTU4000
1162	5279870435	SEAL OIL PAN 4569LG	MTU4000
1163	5240140080	GASKET	MTU4000
1164	006796012100	WASHER SPRING 12 FST DIN 6796 DBL 84	MTU4000
1165	000000000670	CLAMP	MTU4000
1166	X00030632	HOSE INTAKE(X52701800011)	MTU4000
1167	000939012023	STUD	MTU4000
1168	000908038000	PLUG	MTU4000
1169	000908026005	PLUG	MTU4000
1170	23540425	GEAR IDLER ASM GEAR CASE HSG	MTU4000
1171	5240310171	BOLT 12 PT HD	MTU4000
1172	5240520503	GEAR CRANKSHAFT	MTU4000
1173	700429418000	O-RING	MTU4000
1174	5240372525	PISTON CROWN	MTU4000
1175	001481005017	PIN SPRING	MTU4000

1176	5240370276	PRESSURE PLATE	MTU4000
1177	5249900719	BOLT PISTON M91.0X56.5	MTU4000
1178	5240383111	CONROD BEARING SIZE 0-0(X00040714)	MTU4000
1179	23540423	GEAR CAMSHAFT	MTU4000
1180	5240521448	WHEEL SRS MDEC	MTU4000
1181	000007010111	PIN DOWEL CAMSHAFT	MTU4000
1182	5240550550	BUSHING	MTU4000
1183	5240550650	BUSHING	MTU4000
1184	5550540174	PIN	MTU4000
1185	X52408100002	LINK(0000910124)	MTU4000
1186	5270700081	TUBE FUEL	MTU4000
1187	5270700181	TUBE FUEL	MTU4000
1188	5270700281	TUBE FUEL	MTU4000
1189	5260700381	TUBE ASM LOW PRESS FUEL RETURN 860	MTU4000
1190	5260700481	TUBE ASM LOW PRESS FUEL RETURN 820	MTU4000
1191	700429074000	O-RING	MTU4000
1192	XP52499100001	O-RING(700429015000)	MTU4000
1193	000471026000	SNAP RING	MTU4000
1194	700336150004	SLEEVE RUBBER(X00044065)	MTU4000
1195	23540560	CLAMP(5249970090)	MTU4000
1196	5240940042	CLAMP	MTU4000
1197	23526689	SPRING	MTU4000
1198	5319972245	SEALING RING	MTU4000
1199	5272010805	SHAFT WTR PMP HI TEMP CLG CIRCUIT	MTU4000
1200	X00008653	IMPELLER	MTU4000
1201	X00021750	GEAR	MTU4000
1202	X00021730	GASKET	MTU4000
1203	X00008657	IMPELLER F/ENGINE COOLANT PM	MTU4000
1204	900288076002	CLAMP	MTU4000
1205	5272030552	RESTRICTOR	MTU4000
1206	5241550015	PULLEY ALTERNATOR 8 PK POLY-VEE GR'	MTU4000
1207	X00018265	SHAFT FOR DRIVE	MTU4000
1208	X00018270	GEAR FOR DRIVE	MTU4000
1209	23509204	RING RET ACSRY DRV LRG BALL BRG	MTU4000
1210	23511745	BEARING NDL ROLLER HVY DTY ACSRY	MTU4000
1211	23511746	RING RET INT 187 HVY DTY ACSRY DRV	MTU4000
1212	23523995	SEALING RING	MTU4000
1213	X00018266	PULLEY ACCESSORY DRIVE C23	MTU4000
1214	3521550650	RUBBER SHOCK MOUNT	MTU4000
1215	X00042707	COOLER CORE FOR ENGINE COOLANT	MTU4000
1216	X00036149	FAN COOLER WITH ELECTRIC MOTOR	MTU4000
1217	X00036132	EXHAUST PIPE BELLOWS	MTU4000
1218	X00036133	SET OF FUEL HOSES	MTU4000
1219	X00035982	CIRCULATING PUMP	MTU4000
1220	X00036120	SET OF COOLANT HOSES	MTU4000
1221	X00036158	HOSE CLAMP SET	MTU4000
1222	X00041481	VENT HOSE	MTU4000
1223	X00036143	SENSOR	MTU4000
1224	X00042718	COOLER CORE F/CHARGE-AIR COOL	MTU4000
1225	X00041452	FUEL HOSE	MTU4000
1226	X00041444	FUEL HOSE	MTU4000
1227	X00041461	FUEL HOSE	MTU4000
1228	X00041448	FUEL HOSE	MTU4000
1229	X00041470	FUEL HOSE	MTU4000

1230	X00036152	BALL BEARING	MTU4000
1231	X00041375	HOSE CLAMP	MTU4000
1232	X00041381	HOSE CLAMP	MTU4000
1233	X00037971	RECTIFIER UNIT	MTU4000
1234	X00036041	VOLTAGE REGLATOR	MTU4000
1235	X00037228	VARICOMP MODULE	MTU4000
1236	X00043887	TRANSFORMER	MTU4000
1237	X00042151	COOLANT HOSE	MTU4000
1238	X00042152	COOLANT HOSE	MTU4000
1239	X00042153	COOLANT HOSE	MTU4000
1240	X00036015	SEALING KIT	MTU4000
1241	8690920032	GASKET KIT(8695860572)	MTU4000
1242	8690920033	GASKET KIT(8695860572)	MTU4000
1243	8690920039	GASKET KIT(8695860572)	MTU4000
1244	5275302625	WIRING HARNESS TO INJECTOR	MTU4000
1245	5275302725	WIRING HARNESS FOR ON-ENGINE SE	MTU4000
1246	5205304531	PRESSURE SENSOR(8695300131)	MTU4000
1247	700429380002	O-RING	MTU4000
1248	5240336201	MAIN BRG 0-1	MTU4000
1249	5240336702	MAIN BRG 0-1	MTU4000
1250	5240332608	BEARING THRUST/0-1/UP/RIL	MTU4000
1251	5240333407	BEARING THRUST/0-1/LO/SPT	MTU4000
1252	5240384210	RD BRG 0-1	MTU4000
1253	X000040715	BEARING ROD/0-1/L0(5240383211)	MTU4000
1254	5240383211	BEARING ROD/0-1/L0(X000040715)	MTU4000
1255	X52421300006	ALTERNATOR(X00005848)	MTU4000
1256	X00005848	ALTERNATOR(X52421300006)	MTU4000
1257	X00041229	CONTROL UNIT	MTU4000
1258	X00041316	CONTROL SYSTEM	MTU4000
1259	X00041255	CIRCUIT BREAKER	MTU4000
1260	X52417200001	STARTER(0051510001)	MTU4000
1261	0051510001	STARTER(X52417200001)	MTU4000
1262	0041519901	STARTER(X52417200001)	MTU4000
1263	X00036419	FAN COOLER WITH ELECTRIC MOTOR	MTU4000
1264	X00036018	FUEL TRANSFER PUMP	MTU4000
1265	X00042719	COOLER CORE FOR FUEL	MTU4000
1266	5240372325	PISTON CROWN	MTU12V4000
1267	5249970692	BELT POLY-V 4.26 WIDTH 105.50	MTU12V4000
1268	DDE23521563	HOSE(23521563)	MTU12V4000
1269	23521563	HOSE(DDE23521563)	MTU12V4000
1270	DB110333	HOSE	MTU12V4000
1271	DB130286	HOSE	MTU12V4000
1272	DH110310	HOSE	MTU12V4000
1273	0269976782	VENT HOSE	MTU12V4000
1274	5272010605	COOLANT PUMP SHAFT	MTU12V4000
1275	DDE23511745	BEARING NDL ROLLER HVY DTY ACSRY D(23411745)	MTU12V4000
1276	23411745	BEARING NDL ROLLER HVY DTY ACSRY D(DDE23511745)	MTU12V4000
1277	DDE23509203	BEARING BALL ACSRY DRV LRG BRG(23509203)	MTU12V4000
1278	23509203	BEARING BALL ACSRY DRV LRG BRG(DDE23509203)	MTU12V4000
1279	DDE23523995	SEALING RING	MTU12V4000
1280	5241300020	GOV AIR COMPRESSOR BANDIX 277192	MTU12V4000
1281	23527300	PRESSURE SENSOR(0055353831)	MTU12V4000
1282	23540784	SENSOR	MTU12V4000
1283	5261400341	V-BAND CLAMP	MTU12V4000

1284	916016016201	CLIP 16MM DIA X20MM WIDE	MTU12V4000
1285	5241840301	FLTR ELEMENT SPIN ON LUBE OIL FULL FL	MTU12V4000
1286	23540758	ELEMENT BREATHER	MTU12V4000
1287	5240110370	EXTENSION ECM MOUNTING	MTU12V4000
1288	5241420680	GASKET	MTU12V4000
1289	5241310080	GASKET(23540758)	MTU12V4000
1290	5241310280	GASKET	MTU12V4000
1291	5242030580	GASKET	MTU12V4000
1292	5242030480	GASKET	MTU12V4000
1293	5279870035	PROFILE RUBBER	MTU12V4000
1294	5249970945	O-RING	MTU12V4000
1295	5319972845	SEALING RING	MTU12V4000
1296	23520346	SEALING RING	MTU12V4000
1297	5261420557	SEALING RING	MTU12V4000
1298	700429122001	O-RING	MTU12V4000
1299	8499970200	O-RING	MTU12V4000
1300	E23540903	DRIVE	MTU12V4000
1301	2354094	BEARING THRUST KIT PAIR 0-0	MTU16V4000
1302	X00042197	VLAVE INTAKE STD FLOATING BRIDGE	MTU16V4000
1303	X52404100027	VALVE SEAT INSERT SIZE 0	MTU16V4000
1304	23533957	KIT BEARING ROD PAIR/O-O/S4000	MTU16V4000
1305	23540940	BEARING THRUST KIT PAIR 0-0	MTU16V4000
1306	23533882	KIT BEARING MAIN PAIR/O-O/4000	MTU16V4000
1307	EX52620200081	WATERPUMP	MTU16V4000M90
1308	5242370641	BRACKET	MTU4000
1309	X59499100044	GASKET	MTU4000
1310	X52614100006	EXHAUST PIPE	MTU4000
1311	X52614100007	EXHAUST PIPE	MTU4000
1312	5241420553	SPACER SLEEVE	MTU4000
1313	X52418500006	OIL LINE F/TURBOCHARGER(X00038531)	MTU4000
1314	X59507300001	HP PUMP	MTU4000
1315	X59308700003	LEAK-OFF FUEL TANK	MTU4000
1316	915013004002	UNION	MTU4000
1317	915005004000	CONE SEALING 6	MTU4000
1318	X59308600002	FUEL LINE	MTU4000
1319	X00020266	HAND PUMP(5240900950)	MTU4000
1320	5240900950	HAND PUMP(X00020266)	MTU4000
1321	X00027068	TUBE FUEL DOUBLE WALL	MTU4000
1322	X52607700009	ADAPTER JACKETED(X00027086)	MTU4000
1323	X00027086	ADAPTER JACKETED(X52607700009)	MTU4000
1324	X59407800001	BLOCK FUEL DISTIBUTOR DOUBLE WALL	MTU4000
1325	X00039528	TUBE FUEL RETURN 2 BANJO	MTU4000
1326	X00039530	TUBE FUEL RETURN DOUBLE BANJO U SH	MTU4000
1327	915047006202	BOLT BANJO B ADEC	MTU4000
1328	X00034967	VLV PRSR RELIEF 2000 BAR 16V/20V4000	MTU4000
1329	700429036003	O-RING	MTU4000
1330	304017008091	BOLT HEX ZNPH R5F	MTU4000
1331	XP52407700002	SEALING RING	MTU4000
1332	XP52407700001	O-RING	MTU4000
1333	XP52407700003	SNAP RING	MTU4000
1334	X00042421	FILTER FUEL SPIN-ON 8BAR	MTU4000
1335	X00E50202753/S0001	HOUSING WITHOUT INTELOCK	MTU4000
1336	X52417200007	STARTER ELECTRIC(X52417200006)	MTU4000
1337	X52417200006	STARTER ELECTRIC (X5241720000	MTU4000

1338	0002039996	COOLANT PREHEATER ASM AC 440V 50/6	MTU4000
1339	X00E50200123/S0003	SOFTWARE FOR ELECTRONICS	MTU4000
1340	8699810051	GROOVED BALL BEARING DRIVING END	MTU16V4000
1341	8699810049	GROOVED BALL BEARING REAR	MTU16V4000
1342	5241310001	COMPRESSOR	MTU16V4000
1343	23526061	GASKET KIT	MTU16V4000
1344	23526065	KIT GASKET L+H PRESS	MTU16V4000
1345	23526068	KIT GASKET TURBO	MTU16V4000
1346	23526071	KIT GASKET OIL DIST	MTU16V4000
1347	23526064	GASKET KIT	MTU16V4000
1348	23526074	KIT GASKET FAN CLUTC	MTU16V4000
1349	5240350324	RING ASM(0000171160)	MTU16V4000
1350	5240350424	RING ASM(0000171160)	MTU16V4000
1351	5240550505	CAM SWING FOLLOWER AXLE	MTU16V4000
1352	23540102	FITTING M12-1.5 TO 9/16-18 (915006004002)	MTU16V4000
1353	23540111	TUBE ASM HP PUMP VENT ORFS(5244760301)	MTU16V4000
1354	5244760301	TUBE ASM HP PUMP VENT ORFS(23540111)	MTU16V4000
1355	5249970078	COUPLING RING	MTU16V4000
1356	200625906333	BEARING BALL GROOVED 6307 J C04	MTU16V4000
1357	8695860569	PARTS KIT	MTU16V4000
1358	200625906334	GROOVED BALL BEARING	MTU16V4000
1359	23540165	HARNESS 16V	MTU16V4000
1360	23540164	HARNESS 16V	MTU16V4000
1361	11505769	BOLT 12PT	MTU16V4000
1362	E0010108151	INJECTOR	MTU16V4000M90
1363	X00042954	BELT POLY-VEE 8PK 1050 LB ALTERANTOR(23540397)	MTU16V4000
1364	E5260701601	HP PUMP(0050708301)	MTU16V4000
1365	0050708301	HP PUMP(E5260701601)	MTU16V4000
1366	RX52407500021	INJECTOR(23526589)	MTU16V4000
1367	23526589	INJECTOR(RX52407500021)	MTU16V4000
1368	5240160419	SEAL RING INJECTOR(23540260)	MTU16V4000
1369	X00008647	PUMP ASM WTR HI TEMP CLG CIRCUIT(X52620200081)	MTU16V4000
1370	X52703500005	BRUSH CARBON(5271540014)	MTU16V4000
1371	000000001465	BOLT HEX A3C(08929357)	MTU16V4000
1372	0080965599	TURBO ASM	MTU16V4000
1373	0000175052	COMPENSATING WASHER	MTU16V4000
1374	EX00008369	PISTON	MTU16V4000M90
1375	CX00008369	CORE DEPOSIT FOR PISTON	MTU16V4000M90
1376	524051021	CAMSHAFT BEARING SIZE 1-0	MTU12V4000
1377	007349013002	WASHER(7349013002)	MTU12V4000
1378	7349013002	WASHER(007349013002)	MTU12V4000
1379	X52703500006	COLLECTOR(X52703500019)	MTU12V4000
1380	X52703500019	COLLECTOR(X52703500006)	MTU12V4000
1381	X00008371	PISTON	MTU12V4000
1382	X00043218	BEARING ROD/0-0/LO/SPUT	MTU12V4000
1383	X52603800003/42	CONROD ASM	MTU12V4000
1384	X52407500021	INJECTOR	MTU12V4000
1385	200433013000	WASHER	MTU12V4000
1386	304017012018	BOLT HEX	MTU12V4000
1387	5249902501	MULTI-CORNERED SCREW	MTU12V4000
1388	X00005151	RING	MTU12V4000
1389	X00004034	SLEEVE	MTU12V4000
1390	X00002326	SPRING	MTU12V4000
1391	X00002299	SLEEVE	MTU12V4000

1392	5261420553	TUBE TURBO EXH	MTU12V4000
1393	5261420480	GASKET	MTU12V4000
1394	20093308014	BOLT	MTU12V4000
1395	200931012005	BOLT CU 5 BK	MTU12V4000
1396	000000003893	WASHER	MTU12V4000
1397	5249910160	PIN	MTU12V4000
1398	23511667	SPACER	MTU12V4000
1399	5241871853	SPACER SLEEVE	MTU12V4000
1400	304017010051	BOLT HEX	MTU12V4000
1401	304014010013	BOLT HEX	MTU12V4000
1402	5241840501	FLTR ELEMENT SPIN ON LUBE OIL FULL FL(5241840301)	MTU12V4000
1403	5319970245	SEALING RING	MTU12V4000
1404	8699970287	SEALING RING	MTU12V4000
1405	XP52625300004	GROOVED BALL BEARING	MTU12V4000
1406	XP52625300014	O - RING	MTU12V4000
1407	XP52625300020	GROOVED BALL BEARING	MTU12V4000
1408	XP52625300023	SPEAL PLUG	MTU12V4000
1409	23530646	FILTER ELEMENT(0020920401)	MTU12V4000
1410	0020920401	FILTER ELEMENT(23530646)	MTU12V4000
1411	E5240106920	CYLINDER HEAD(5240106920)	MTU16V4000G61
1412	5240106920	CYLINDER HEAD(E5240106920)	MTU16V4000G61
1413	C5240106920	CORE DEPOSIT FOR CYLINDER HEAD	MTU16V4000G61
1414	23526699	VALVE AND SPRING KIT	MTU16V4000G61
1415	EX52603800003/42	CONROD ASM(X52603800003/42)	MTU16V4000G61
1416	CX52603800003/42	CORE DEPOSIT FOR CON ROD	MTU16V4000G61
1417	X52408100006	FUEL DELIVERY PUMP	MTU16V4000G61
1418	R5260701201	HP PUMP	MTU16V4000G61
1419	CR5260701201	CORE DEPOSIT FOR HP PUMP	MTU16V4000G61
1420	B120439	AIR FILTER	MTU16V4000G61
1421	EX52404100035	CYLINDER HEAD(X52404100035)	MTU16V4000G61
1422	X52404100035	CYLINDER HEAD(EX52404100035)	MTU16V4000G61
1423	CX52404100035	CORE DEPOSIT FOR CYLINDER HEAD	MTU16V4000G61
1424	5240530032	VALVE SEAT INSERT EXHAUST	MTU16V4000G61
1425	X52417200003	MTR ELEC START 24V PRESTOLITE MS7-5	MTU16V4000G61
1426	X52417200004	MTR ELEC START 24V PRESTOLITE MS7-5	MTU16V4000G61
1427	P551402	FILTER	MTU16V4000G61
1428	23540465	PAPER ELEMENT	MTU16V4000G61
1429	23540783	KIT PRESS SENSOR(23526562)	MTU16V4000C20
1430	23526562	KIT PRESS SENSOR(23540783)	MTU16V4000C20
1431	8691540049	GOVERNOR	MTU16V4000C20
1432	23540377	PRESSURE SENSOR	MTU16V4000C20
1433	5241700440	MOTOR START AIR RB CW 150	MTU16V4000C20
1434	P105535	RUBBER ELBOW 90DEG(23560428)	MTU16V4000C20
1435	23560428	RUBBER ELBOW 90DEG(P105535)	MTU16V4000C20
1436	23560429	CLAMP 6" HOSE DONA	MTU16V4000C20
1437	5355302375	TEST UNIT FOR ECU	MTU4000 PARTS
1438	5355301260	TEST/SERVICE UNIT FOR ECU	MTU4000 PARTS
1439	5281420057	SEALING RING	MTU4000
1440	5205351305	FLOE MONITOR	MTU16V4000M70
1441	5285300660	HOUSING F/OPR DATA COMPUTER	MTU16V4000M70
1442	RX52407500024	INJECTOR	MTU4000
1443	8691840027	ROTOR COMPLETE	MTU4000
1444	5260900376	TUBE ASM DBL WALL FUEL HP PMP TO LB	MTU4000
1445	X52607700032	HP FUEL LINE HACKETED(5260900776)(23540110)	MTU4000

1446	5260900776	HP FUEL LINE HACKETED(X52607700032)(23540110)	MTU4000
1447	5240701533	HP LINE	MTU4000
1448	0011420659	BELLOWS	MTU4000
1449	0001426823	INSULATION	MTU4000
1450	X00007116	V-BAND CLAMP	MTU4000
1451	0001426557	SEALING RING	MTU4000
1452	0014909265	BELLOWS	MTU4000
1453	X00007115	V-BAND CLAMP	MTU4000
1454	23519309/76	ELECTRONIC GOVERNOR NOT ADJUSTEC	MTU SERIE12V4000
1455	0005300534	WIRING HARNESS(0005302434)	MTU SERIE12V4000
1456	0005302434	WIRING HARNESS(0005300534)	MTU SERIE12V4000
1457	23540916	WIRING HARNESS	MTU SERIE12V4000
1458	0005302134	WIRING HARNESS	MTU SERIE12V4000
1459	23524595	PRESSURE SENSOR(0055353731)	MTU SERIE12V4000
1460	53540377	HARNESS ASM	MTU SERIE12V4000
1461	T80091391	LIFTING EQUIPMENT	MTU4000SPECZAL TOOLS
1462	T80091105	LIFTING EQUIPMENT	MTU4000SPECZAL TOOLS
1463	T80091387	SHACKLE	MTU4000SPECZAL TOOLS
1464	F0140440	MOUNT/FORCE-OFF DEV	MTU4000SPECZAL TOOLS
1465	F6781739	ASSEMBLY DEVICE	MTU4000SPECZAL TOOLS
1466	F6781675	GUIDE SLEEVE(F6784403)	MTU4000SPECZAL TOOLS
1467	F6780579	GUIDE SLEEVE	MTU4000SPECZAL TOOLS
1468	F6781676	GUIDE SLEEVE	MTU4000SPECZAL TOOLS
1469	B80144857	ADAPTER	MTU4000SPECZAL TOOLS
1470	F6555792	POINTER	MTU4000SPECZAL TOOLS
1471	F6555764	PRESS-IN DEVICE	MTU4000SPECZAL TOOLS
1472	F6553653	INSERTION SLEEVE	MTU4000SPECZAL TOOLS
1473	F6553647	INSTALL/REMOVE DEV.	MTU4000SPECZAL TOOLS
1474	F6783567	INSTALLATION DEV.	MTU4000SPECZAL TOOLS
1475	F6787778	REMOVAL TOOL(F6783568)	MTU4000SPECZAL TOOLS
1476	F6783568	REMOVAL TOOL(F6787778)	MTU4000SPECZAL TOOLS
1477	F6557122	ASSEMBLY SLEEVE(F6553652)	MTU4000SPECZAL TOOLS
1478	5115890021/00	FEELER GAUGE	MTU4000SPECZAL TOOLS
1479	F0099977	PRESS.TEST RIG	MTU4000SPECZAL TOOLS
1480	F30011640	SOCKET WRENCH BIT	MTU4000SPECZAL TOOLS
1481	F30278533	CROWFOOT WRENCH	MTU4000SPECZAL TOOLS
1482	F30370328	HYD.INSTALLTION TOOL	MTU4000SPECZAL TOOLS
1483	F30378717	ASSEMBLY PLIERS	MTU4000SPECZAL TOOLS
1484	F30379907	DBLE OPEN-END WRENCH	MTU4000SPECZAL TOOLS
1485	F30510059	SOCKET WRENCH BIT	MTU4000SPECZAL TOOLS
1486	F30520703	TORQUE WRENCH	MTU4000SPECZAL TOOLS
1487	F6558076	ASSEMBLY TEMPLATE	MTU4000SPECZAL TOOLS
1488	F6558092	GUARD CAP	MTU4000SPECZAL TOOLS
1489	F70144375	WISE JAW	MTU4000SPECZAL TOOLS
1490	5505890921/00	COMPRESSION PRESS RECORDER	MTU4000SPECZAL TOOLS
1491	5265341605	CONTROL UNIT W/MANUAL CONTROL	MTU16V4000M70
1492	X00E50202270	SPARE PARTS KIT FOR DISPLAY UNIT(5005361200)	MTU16V4000M70
1493	5005361200	SPARE PARTS KIT FOR DISPLAY UNIT(X00E50202270)	MTU16V4000M70
1494	5275304760	GOVERNOR NOT ADJUSTED(X00E50206616/76)	MTU16V4000M70
1495	5275304360/S0003	HOUSING(5275304360)	MTU16V4000M70
1496	5275304360	HOUSING(5275304360/S0003)	MTU16V4000M70
1497	0005461220	EARTHING STRIP	MTU16V4000M70
1498	200912006001	BOLT HEX SOC HD	MTU16V4000M70
1499	X00E50700032	WIRING HARNESS FOR ON-ENGINE SE(5275306422)	MTU16V4000M70

1500	5275306422	WIRING HARNESS FOR ON-ENGINE SE(X00E50700032)	MTU16V4000M70
1501	5275302925	WIRING HARNESS FOR ON-ENGINE SE(5275306522)	MTU16V4000M70
1502	5275306522	WIRING HARNESS FOR ON-ENGINE SE(5275302925)	MTU16V4000M70
1503	5275305222	WIRING HARNESS TO INHECTOR	MTU16V4000M70
1504	5275306822	WIRING HARNESS FOR ON=ENGINE SNESOR	MTU16V4000M70
1505	X00E50700031	WIRING HARNESS FOR ON-ENGINE(5275307122)	MTU16V4000M70
1506	5275307122	WIRING HARNESS FOR ON-ENGINE(X00E50700031)	MTU16V4000M70
1507	5005309236	CABLE W/MALE CONNECTOR	MTU16V4000M70
1508	5265303735	CABLE W/MALE CONNECTOR	MTU16V4000M70
1509	X00E50207199	PRESSURE SENSOR(0045358831)	MTU16V4000M70
1510	X00E50207196	PRESSURE SENSOR(0035351731)	MTU16V4000M70
1511	000535630	TEMPERATURE SENSOR	MTU16V4000M70
1512	EX52620300023	PUMP ASM WTRLOW TEMP CLG CIRCUIT(E23537096)	MTU12V4000C
1513	E23537096	PUMP ASM WTRLOW TEMP CLG CIRCUIT(EX526203000)	MTU12V4000C
1514	CX52620300023	CORE DEPOSIT WATER PUMP	MTU12V4000C
1515	EX52420200011	COOLANT PUMP HIGH-TEMP CIRCUIT(E23537085)	MTU12V4000C
1516	E23537085	COOLANT PUMP HIGH-TEMP CIRCUIT(EX52420200011)	MTU12V4000C
1517	CX52420200011	CORE DEPOSIT WATER PUMP	MTU12V4000C
1518	5242030380	GASKET	MTU12V4000C
1519	X52407500023	INJECTOR(EX52407500023)	MTU16V4000C
1520	CX52407500023	CORE DEPOIST FOR INJECTOR	MTU16V4000C
1521	5240900976	TUBE ASM DBL WALL FUEL HP PMP TO LB	MTU16V4000C
1522	5240900876	TUBE ASM WALL HP FUEL CROSSOVER	MTU16V4000C
1523	5240780824	CONN FUEL RAIL REAR	MTU16V4000C
1524	007603026101	WASHER A COP S2000/4000(007603026104)	MTU16V4000C
1525	0010928701	PREFIL TER FUEL ASSEMBLY 18 LPM	MTU16V4000C
1526	8695860571	GASKET KIT	MTU16V4000C
1527	X52808100004	FUEL DELIVERY PUMP(X00010945)	MTU16V4000C
1528	X00010945	FUEL DELIVERY PUMP (X52808100004)	MTU16V4000C
1529	X52807700001	HP FUEL LINE SINGLE-WALLED,LEFT	MTU16V4000C
1530	X52807700002	HP FUEL LINE SINGLE-WALLED,RIGH	MTU16V4000C
1531	5280780090	HP ACCUMULATOR	MTU16V4000C
1532	5272500101	DIAPHRAGM COUPLING(5242500401)	MTU12V4000
1533	5242500401	DIAPHRAGM COUPLING(5272500101)	MTU12V4000
1534	X52705100010	CAMSHAFT FOR 16V	MTU12V4000
1535	X52405500086	CULINDER HEAD COVER F/CRANKCASEV	MTU12V4000
1536	E5260301101	CR/SHFT ASM(5260300701)	MTU12 16V4000
1537	C5260301101	CORE DEPOSIT CRANKSHAFT	MTU12 16V4000
1538	E5270301301	CRANKSHAFT ASM(5270300401)	MTU12 16V4000
1539	5270300401	CRANKSHAFT ASM(E5270301301)	MTU12 16V4000
1540	C5270301301	CORE DEPOSIT CRANKSHAFT	MTU12 16V4000
1541	5270500101	CAMSHAFT FOR 16V(X52705100010)	MTU12 16V4000
1542	5240530705	EXHAUST VALVE(5240530905)	MTU12V4000M60
1543	0015341801	PUSHBUTTON	MTU12V4000M60
1544	E5260700801	HP PUMP(E5260701201)	MTU12V4000M60
1545	C5260701201	CORE DEPOSIT	MTU12V4000M60
1546	8690740395	SOLENOID(8690740389)	MTU12V4000M60
1547	8690740389	SOLENOID(8690740395)	MTU12V4000M60
1548	5281880080	GASKET	MTU12V4000G23
1549	EX52404100045	CYLINDER HEAD(X52404100011)	MTU12V4000G23
1550	X52404100011	CYLINDER HEAD(EX52404100045)	MTU12V4000G23
1551	CX52404100045	CORE DEPOSIT CYL.HEAD	MTU12V4000G23
1552	X00034966	VLV PRSR RELIEF 2000BAR 16V/20V4000(X00034967)	MTU12V4000G23
1553	X00028861	RAIL FUEL HIGH PRESS SGL WALL B-BAN	MTU12V4000G23

1554	X00028860	RAIL FUEL HIGH PRESS SGL WALL B-BAN	MTU12V4000G23
1555	5240702133	HP FUEL LINE SINGLE-WALL	MTU12V4000G23
1556	X00027842	HP FUEL LINE SINGLE-WALL LEFT	MTU12V4000G23
1557	X52607700010	HP FUEL LINE SINGLE-WALL(X00018223)	MTU12V4000G23
1558	X00018223	HP FUEL LINE SINGLE-WALL(X52607700010)	MTU12V4000G23
1559	X00004208	TUBE FUEL RETURN 161.548	MTU12V4000G23
1560	X00034974	TUBE FUEL LOW PRESSURE RETURN	MTU12V4000G23
1561	0001400682	BELLOWS EXHAUST	MTU12V4000G23
1562	X52418500002	OIL LINE F/TURBOCHARGER(X52418500006)	MTU12V4000G23
1563	5241806520	TUBE ASM TURBO OIL DRAIN A-BANK	MTU12V4000G23
1564	23511786	BOLT PHOS HEX FLG LRG 6174M	MTU12V4000G23
1565	0135315483	PLIERS(135315483)	MTU16V4000
1566	135315483	PLIERS(0135315484)	MTU16V4000
1567	F30039518	BOX WRENCH BIT	MTU16V4000
1568	Y4345711	TEST DEVICE T3	MTU16V4000
1569	F6790161	FITTING/REMOVAL DEV(F30377769)	MTU16V4000
1570	F6557952	FITTING/REMOVAL DEV(F6790161)	MTU16V4000
1571	F6555197	FITTING/REMOVAL DEV(F6790161)	MTU16V4000
1572	F30452578	SLOTTED NUT DRIVER(F30379005)	MTU16V4000
1573	F30379005	SLOTTED NUT DRIVER(F30452578)	MTU16V4000
1574	5605892099/00	TEST KIT	MTU16V4000
1575	X00017505	SPARE PARTS KIT FOR FUEL FILTER	MTU4000PARTS
1576	5280330362	WASHER THRUST FLYWHL HSG	MTU16V4000G23
1577	X59305200001	IDLER GEAR(23540425)	MTU16V4000G23
1578	0021806201	O/PUMP ASM	MTU16V4000G23
1579	735151010200	SPACER S2000/4000	MTU16V4000G23
1580	X59518300006/87	OIL HEAT EXCHANGER WITH TEST CERT(5261800465/87)	MTU16V4000G23
1581	5261800465/87	OIL HEAT EXCHANGER WITH TEST CERT(X59518300006)	MTU16V4000G23
1582	23540470	SUPPL FEED VALVE	MTU16V4000G23
1583	EX59507300003	HP PUMP	MTU16V4000G23
1584	CX59507300003	CORE DEPOSIT HIGH PRESSURE PUMP	MTU16V4000G23
1585	X52802600011	DRIVE FOR ATT HARDWARE	MTU16V4000G23
1586	700429044001	O-RING	MTU16V4000L62
1587	X00005776	AIR FILTER	MTU16V4000L62
1588	0000901451	FILTER ELEMENT	MTU4000
1589	304014010023	HEX SCREW	MTU16V4000G23
1590	X59407700002	TUBE FUEL SINGLE WALL-03 GENSET C23	MTU16V4000G23
1591	X52407700014	ADAPTER	MTU16V4000G23
1592	5244700207	VALVE	MTU16V4000G23
1593	XP52799100643	O-RING(5319970545)	MTU16V4000G23
1594	5319970545	O-RING(XP52799100643)	MTU16V4000G23
1595	5241420302	OUTLET TURBO EXHAUST	MTU16V4000G23
1596	5511531250	SPACER BUSHING	MTU16V4000G23
1597	X00004067	MANIFOLD EXHAUST CENTER	MTU16V4000G23
1598	000912016002	BOLT HEX SOC HD	MTU16V4000G23
1599	5281800319	TUBE HIGH PRESS FUEL PUMP LUBE OIL	MTU16V4000G23
1600	5241806620	TUBE ASM TURBO OIL DRAIN A-BANK	MTU16V4000G23
1601	X00032477	WIRING HARNESS TO INJECTOR	MTU16V4000G23
1602	5240780050	BUSHING	MTU16V4000G23
1603	X00025230	CONTROL BLOCK	MTU16V4000G23
1604	EX59403700005	PISTON (EX59403700017)	MTU16V4000G23
1605	CX59403700017	CORE DEPOSIT CYL.HEAD	MTU16V4000G23
1606	EX52710100036	EXHAUST TURBOCHARER	MTU16V4000G23
1607	CX52710100036	CORE DEPOSIT TURBO CHARGER	MTU16V4000G23

1608	P552020	FILTER	MTU16V4000G23
1609	F30452561	TOOL KIT	MTU4000SPECIAL TOOLS
1610	8205892061/00	ASSEMBLY MIRROR	MTU4000SPECIAL TOOLS
1611	8205892961/03	MAGNET HEAD M10X1	MTU4000SPECIAL TOOLS
1612	F30002785	DOUBLE OPEN END WRENCH	MTU4000SPECIAL TOOLS
1613	F30004455	OPEN-END WRENCH	MTU4000SPECIAL TOOLS
1614	F30006068	D.EOPEN -JAW WRENCH	MTU4000SPECIAL TOOLS
1615	F30006129	SOCKET WRENCH BIT	MTU4000SPECIAL TOOLS
1616	F30011450	WRENCH RING DE O/SET	MTU4000SPECIAL TOOLS
1617	F30022000	WRENCH RING DE O/SET	MTU4000SPECIAL TOOLS
1618	F30024325	SPIDER PATCH SPANNER	MTU4000SPECIAL TOOLS
1619	F30025097	SOCKET WRENCH ADAPTER	MTU4000SPECIAL TOOLS
1620	F30027426	CROWFOOT BOX WRENCH	MTU4000SPECIAL TOOLS
1621	F30028347	SOCKET BOX WRENCH	MTU4000SPECIAL TOOLS
1622	F30029815	OJ ADAPTER	MTU4000SPECIAL TOOLS
1623	F30029816	OJ ADAPTER	MTU4000SPECIAL TOOLS
1624	F30039530	BOX SOCKET WRENCH	MTU4000SPECIAL TOOLS
1625	F30452768	TORQUE WRENCH	MTU4000SPECIAL TOOLS
1626	F30452769	TORQUE WRENCH	MTU4000SPECIAL TOOLS
1627	F30452774	TORQUE SCREWDRIVER	MTU4000SPECIAL TOOLS
1628	F30501569	EXTENSION OFFSET	MTU4000SPECIAL TOOLS
1629	F30515239	PRY BAR WITH DOG	MTU4000SPECIAL TOOLS
1630	F30516143	EXTENSION ROTATABLE	MTU4000SPECIAL TOOLS
1631	Y20098771	FEELER GAUGE	MTU4000SPECIAL TOOLS
1632	F30452564	TOOL KIT	MTU4000SPECIAL TOOLS
1633	F6558528	ADAPTER	MTU4000SPECIAL TOOLS
1634	F6783293	BARRING DEVICE	MTU4000SPECIAL TOOLS
1635	F6792918	BARRING GEAR(F6787910)	MTU4000SPECIAL TOOLS
1636	F6787910	BARRING GEAR(F6792918)	MTU4000SPECIAL TOOLS
1637	3435890040/00	BRACKET	MTU4000SPECIAL TOOLS
1638	F30028269	CHUCKING REAMER	MTU4000SPECIAL TOOLS
1639	F30047578	CHUCKING REAMER	MTU4000SPECIAL TOOLS
1640	F30091631	CHUCKING REAMER	MTU4000SPECIAL TOOLS
1641	F30377635	INSTALLATION MANDREL	MTU4000SPECIAL TOOLS
1642	F30378316	INSTALLATION JIG	MTU4000SPECIAL TOOLS
1643	F30378617	INSTALLATION MANDREL	MTU4000SPECIAL TOOLS
1644	F30377862	GUIDE SLEEVE	MTU4000SPECIAL TOOLS
1645	F30450348	DRIFT	MTU4000SPECIAL TOOLS
1646	F30450631	VALVE ST GRIND TOOL	MTU4000SPECIAL TOOLS
1647	F30450547	VLVE STGRINDER F.CYL HD(F30450642)	MTU4000SPECIAL TOOLS
1648	F30450642	VLVE STGRINDER F.CYL HD(F30450547)	MTU4000SPECIAL TOOLS
1649	F30450646	VALVE SEAT CTRSINK	MTU4000SPECIAL TOOLS
1650	F70272006	DETACHABLE HOLDER	MTU4000SPECIAL TOOLS
1651	8205890451/00	TURNING HANDLE	MTU4000SPECIAL TOOLS
1652	F30450632	VALVE ST GRIND TOOL	MTU4000SPECIAL TOOLS
1653	F30450643	VALVE SEAT CTRSINK	MTU4000SPECIAL TOOLS
1654	F30450645	VALVE SEAT CTRSINK	MTU4000SPECIAL TOOLS
1655	F70272005	DETACHABLE HOLDER	MTU4000SPECIAL TOOLS
1656	F30450750	PRESS-IN MANDREL	MTU4000SPECIAL TOOLS
1657	F30451080	VALVE ST.CTRSK TOOL	MTU4000SPECIAL TOOLS
1658	F30451081	VALVE SEAT CTRSINK	MTU4000SPECIAL TOOLS
1659	F30451082	VALVE SEAT CTRSINK	MTU4000SPECIAL TOOLS
1660	F30451554	DRILL/REAMING TOOL	MTU4000SPECIAL TOOLS
1661	F30515760	SOCKET WRENCH INSERT	MTU4000SPECIAL TOOLS

1662	F6553658	ANGLE-OF-ROT,JIG	MTU4000SPECIAL TOOLS
1663	F6554300	ASSEMBLY PLATE	MTU4000SPECIAL TOOLS
1664	F6781747	SHRINK-ON TOOL	MTU4000SPECIAL TOOLS
1665	F6783749	TOOL KIT	MTU4000SPECIAL TOOLS
1666	F30452523	INDEXABLE INSERT(F30452436)	MTU4000SPECIAL TOOLS
1667	F30452436	INDEXABLE INSERT(F30452523)	MTU4000SPECIAL TOOLS
1668	F70026248	SCHRAUBE FUER WSP	MTU4000SPECIAL TOOLS
1669	F70272935	CLAMP	MTU4000SPECIAL TOOLS
1670	F6783750	TOOL KIT	MTU4000SPECIAL TOOLS
1671	Y4347140	TEST RIG	MTU4000SPECIAL TOOLS
1672	F6784421	TOOL KIT	MTU4000SPECIAL TOOLS
1673	F6788255	ALIGNMENT JIG	MTU4000SPECIAL TOOLS
1674	F6790544	ALIGNMENT JIG(F6789471)	MTU4000SPECIAL TOOLS
1675	F6789471	ALIGNMENT JIG(F6790544)	MTU4000SPECIAL TOOLS
1676	Y20090113	ALIGN LIMPL GAUGE	MTU4000SPECIAL TOOLS
1677	Y20091080	ALIGN LIMPL GAUGE	MTU4000SPECIAL TOOLS
1678	Y20097473	ALIGNMENT PLUG GAUGE	MTU4000SPECIAL TOOLS
1679	Y20097512	ALIGN LIM PL GAUGE	MTU4000SPECIAL TOOLS
1680	Y20097513	ALIGN LIM PL GAUGE	MTU4000SPECIAL TOOLS
1681	Y4340442	TEST GAUGE INLET	MTU4000SPECIAL TOOLS
1682	Y4340443	TEST GAUGE EXH	MTU4000SPECIAL TOOLS
1683	F30379258	RATCHET RING WRENCH	MTU4000SPECIAL TOOLS
1684	F30379259	RATCHET RING WRENCH	MTU4000SPECIAL TOOLS
1685	F30452807	RATCHET RING WRENCH	MTU4000SPECIAL TOOLS
1686	F6782353	ASSEMBLY TOOL	MTU4000SPECIAL TOOLS
1687	F6782356	PULLER	MTU4000SPECIAL TOOLS
1688	F6784926	ASSEMBLY JIG F/TURBOCHARGER	MTU4000SPECIAL TOOLS
1689	F6789908	PROTECTIVE CAP F/TURBOCHARGER	MTU4000SPECIAL TOOLS
1690	T80091140	LIFTING JIG	MTU4000SPECIAL TOOLS
1691	T80090748	4-STRAND HOOK CHAIN	MTU4000SPECIAL TOOLS
1692	F6786383	RETAINING JIG	MTU4000SPECIAL TOOLS
1693	F6789270	ALIGNMENT JIG	MTU4000SPECIAL TOOLS
1694	F6789329	ALIGNMENT JIG	MTU4000SPECIAL TOOLS
1695	F6789791	ALIGNMENT JIG	MTU4000SPECIAL TOOLS
1696	F30378152	PRESS-IN TOOL	MTU4000SPECIAL TOOLS
1697	F30275611	MOUNT	MTU4000SPECIAL TOOLS
1698	F30378153	PRESS-IN TOOL	MTU4000SPECIAL TOOLS
1699	F30378550	PRESS-IN TOOL	MTU4000SPECIAL TOOLS
1700	F30450990	INSTALLATION TOOL	MTU4000SPECIAL TOOLS
1701	F30450991	REMOVAL TOOL	MTU4000SPECIAL TOOLS
1702	F6780561	REMOVAL DEVICE	MTU4000SPECIAL TOOLS
1703	F6780562	REMOVAL DEVICE	MTU4000SPECIAL TOOLS
1704	F6780563	AUFLAGE	MTU4000SPECIAL TOOLS
1705	F6780565	AUFLAGE	MTU4000SPECIAL TOOLS
1706	F6781539	HYDR PRESS SPINDLE	MTU4000SPECIAL TOOLS
1707	F6781573	SUPPORT	MTU4000SPECIAL TOOLS
1708	F6785817	PULLER	MTU4000SPECIAL TOOLS
1709	F6788557	PRESS-IN TOOL	MTU4000SPECIAL TOOLS
1710	F6788558	PRESS-IN TOOL	MTU4000SPECIAL TOOLS
1711	F6789813	GUIDE PIN	MTU4000SPECIAL TOOLS
1712	F30453003	OPEN-END WRENCH	MTU4000SPECIAL TOOLS
1713	EX52603800010/42	CONROD ASM	MTU16V4000G3
1714	CX52603800010/42	CORE DEPOSIT CONROD	MTU16V4000G3
1715	700429253000	O-RING(700429250000)	MTU16V4000G3

1716	5240980907	MANIFOLD INTAKE CHRГ AIR CENTER	MTU16V4000G3
1717	CX59403700005	CORE DEPOSIT CYL HEAD	MTU16V4000G3
1718	5240981407	MANIFOLD CHARGE AIR FRONT A-BANK	MTU16V4000G3
1719	0090374919	KEYSTONE COMPR RING	MTU16V4000G3
1720	01830	PRE FUEL FILTER CARTRIDGE	MTU16V4000G23
1721	X00013978	TERMINAL FOR CYLINDER HEAD	MTU16V4000G23
1722	0065319181	TERMINAL	MTU16V4000G23
1723	X00006101	END SLEEVE	MTU16V4000G23
1724	EX00028719	CRANKSHAFT	MTU16V4000G23
1725	CX00028719	CORE DEPOSIT CRANKCASE	MTU16V4000G23
1726	5240110111	CAP MAIN BEARING NARROW STD POSITION(52401102	MTU16V4000G23
1727	5240110211	CAP MAIN BEARING NARROW STD POSITION(52401103	MTU16V4000G23
1728	X00020248	ELBOW SUMP OIL PICKUP ASM	MTU16V4000G23
1729	5242000754	TUBE PLUG-IN -PIPE	MTU16V4000G23
1730	EX52703100001	CRANKSHAFT	MTU16V4000G23
1731	CX52703100001	CORE DEPOSIT CRANKSHAFT	MTU16V4000G23
1732	5270510101	CAMSHAFT FOR 16V(5270500101)	MTU16V4000G23
1733	X52603200007	FLYWHEEL	MTU16V4000G23
1734	5241870201	TUBE D	MTU16V4000G23
1735	5241870101	TUBE D	MTU16V4000G23
1736	5241870401	TUBE D	MTU16V4000G23
1737	X52418400002	RETAINER	MTU16V4000G23
1738	X52418400001	RETAINER	MTU16V4000G23
1739	X59418400008	OIL SPRAY NOZZLE	MTU16V4000G23
1740	C5260701601	CORE DEPOSIT HIGH PRESSURE PUMP	MTU16V4000C21
1741	23525844	GASKET	MTU16V4000C21
1742	5242008351	TUBE ASM	MTU16V4000C21
1743	5242008451	TUBE ASM	MTU16V4000C21
1744	5242008551	TUBE ASM	MTU16V4000C21
1745	5242008651	TUBE ASM	MTU16V4000C21
1746	5261420304	EXH PIPE(5241423004)	MTU16V4000C21
1747	5241423004	EXH PIPE(5261420304)	MTU16V4000C21
1748	X52614200006	EXHAUST PIPE(5261420504)	MTU16V4000C21
1749	X00E50207207	PRESSURE SENSOR(0055353831)	MTU16V4000C21
1750	0005301934	HARNESS INTRFC5500.0 MM EUCLID HITA	MTU16V4000C21
1751	23526526	BOLT	MTU16V4000C21
1752	23526527	BOLT	MTU16V4000C21
1753	X59399100083	CLAMP(5249970090)	MTU16V4000C21
1754	X59599100139	O-RING(5269970045)	MTU16V4000C21
1755	8929357	BOLT HEX A3C(000000001465)	MTU16V4000C21
1756	199629	KIT UPFIT COMPL	MTU16V4000C21
1757	X00E50200509	PRESSURE SENSOR	MTU4000
1758	0055351131	PRESSURE SENSOR	MTU4000
1759	0015368011	TEMPERATURE GAUGE ELECTRIC	MTU4000
1760	0035429405	TEMPERATURE GAUGE ELECTRIC	MTU4000
1761	F30006234	ADAPTER J1/2XA3/8	MTU4000-03TOOL
1762	F30006235	ADAPTOR	MTU4000-03TOOL
1763	F30017884	PIPE WRENCH	MTU4000-03TOOL
1764	F30452764	SCREWDRIVER	MTU4000-03TOOL
1765	F30452765	OFFSET SCREWDRIVER	MTU4000-03TOOL
1766	F30452766	OFFSET SCREWDRIVER	MTU4000-03TOOL
1767	F30452767	TOOLKIT	MTU4000-03TOOL
1768	F30452770	SCREWDRIVER	MTU4000-03TOOL
1769	F30452772	SOCKET	MTU4000-03TOOL

1770	F30452773	SOCKET	MTU4000-03TOOL
1771	F30452771	REDUCER	MTU4000-03TOOL
1772	F30450906	BOX WRENCH	MTU4000-03TOOL
1773	F30452739	MILLING CUTTER	MTU4000-03TOOL
1774	F6790604	TOOL BOX	MTU4000-03TOOL
1775	23530644	FLTR ASM FUEL SEC SPIN ON HIEFFICIEA	MTU4000
1776	EX52407500021	INJECTOR	MTU4000
1777	CX52407500021	CORE DEPOSIT INJECTOR	MTU4000
1778	EX00035690	PISTON	MTU16V4000M73L
1779	CX00035690	CORE DEPOSIT PISTON	MTU16V4000M73L
1780	EX59407500009	INJECTOR	MTU16V4000M73L
1781	CX59407500009	CORE DEPOSIT INJECTOR	MTU16V4000M73L
1782	X59407700023	HP FUELLINE	MTU16V4000M73L
1783	X59407700014	ADAPTER	MTU16V4000M73L
1784	X59512300003	DIVERTERVALVE	MTU16V4000M73L
1785	X52403700066	SNAP RING	MTU16V4000G83
1786	X00E50700373	ENGINE CABLING FOR ON-ENGINE	MTU16V4000R43L
1787	X00E50700127	WIRING HARNESS TO INJECTOR	MTU16V4000R43L
1788	X52405400013	PUSHROD(5240500930)	MTU16V4000G23
1789	XP59307500002	O-RING	MTU16V4000G23
1790	700429010001	O-RING	MTU16V4000G23
1791	23540217	SWITCH PRESSURE M10	MTU16V4000C21
1792	23540184	SWITCH/TIMER	MTU16V4000C21
1793	5240320705	RING GEAR	MTU16V4000C21
1794	E5270101805	CRANKCASE(5270101805)	MTU16V4000
1795	5270101805	CRANKCASE(E5270101805)	MTU16V4000
1796	C5270101805	CORE DEPOSIT CRANKCASE	MTU16V4000
1797	E5260200805	EXHAUST TURBOCHARGER(5260200805)	MTU12V4000G63
1798	C5260200805		MTU12V4000G63
1799	5240780045	BLOCKJUNCTIONMULTI-PORT	MTU16V4000G03
1800	5240981107	MANIFOLD CHARGE AIR FRONT B-BANK	MTU16V4000G03
1801	000908052003	PLUG	MTU16V4000G03
1802	X00004215	TUBE FUEL RETURN LOW PRESSURE B-BANK	MTU16V4000G03
1803	X00032042	CONNECTING PIECE	MTU16V4000G03
1804	700429480000	O-RING	MTU16V4000G03
1805	5240160069/87	CYLINDER HEAD SCREW(5240160069)	MTU16V4000G03
1806	5240370720	PISTON PIN	MTU16V4000G03
1807	X52603500002	COVER PROTECTIVE FOR DAMPER GX3	MTU16V4000G03
1808	X59407800002	BLOCK FUEL DISTIBUTOR SINGLE WALL	MTU16V4000G03
1809	70042915000	O-RING	MTU16V4000G03
1810	XP52707700005	O-RING	MTU16V4000G03
1811	700429018004	O-RING	MTU16V4000G03
1812	5242030780	GASKET	MTU16V4000G03
1813	527230080	GASKET	MTU16V4000G03
1814	5249970392	BELT POLY-V 4.26 WIDTH 104.00	MTU16V4000
1815	X52602400010	EQUIPENT RACK(X00028715)	MTU16V4000
1816	X00028715	EQUIPENT RACK(X52602400010)	MTU16V4000
1817	0005300334	WIRING HARNESS	MTU16V4000
1818	000000004051	BANJOSCREW(23550088)	MTU16V4000
1819	23550088	BANJOSCREW(000000004051)	MTU16V4000
1820	XP52499100226	V-BAND CLAMP(8699950012)	MTU16V4000
1821	8699950012	V-BAND CLAMP(XP52499100226)	MTU16V4000
1822	5270100672	GAGE ASM OIL LEVEL	MTU16V4000
1823	5240100566	TUBE ASM OIL GAUGE	MTU16V4000

1824	5279870535	SEAL LOWER OIL PAN STRIP	MTU16V4000
1825	5279870735	SEAL RUBBER STRIP 5150.0	MTU16V4000
1826	X59402600019	DRIVE FOR ATT.HARDWARE(X00037127)	MTU16V4000
1827	X00037127	DRIVE FOR ATT.HARDWARE(X59402600019)	MTU16V4000
1828	23525733	CYLINDER HEAD SIZE 0(5240114210)	MTU16V4000
1829	EX52404100028	CYLINDER HEAD	MTU16V4000
1830	CX52404100028	CORE DEPOSIT CYLINDER HEAD	MTU16V4000
1831	5249890091	INSULATING RING(23512438)	MTU16V4000
1832	23512438	INSULATING RING(5249890091)	MTU16V4000
1833	DDE5242520006	PLATE COUPLING SCUFF(5242520006)	MTU16V4000
1834	EX00008371	PISTON	MTU16V4000
1835	CX00008371	CORE DEPOSIT PISTON	MTU16V4000
1836	11509528	BOLT PHOS HEX FLG LRG 6174M	MTU16V4000
1837	DDE23514941	PIN(23514941)	MTU16V4000
1838	23514941	PIN(DDE23514941)	MTU16V4000
1839	X00E50207215	PRESSURE SENSOR(X00038950)	MTU16V4000
1840	23526432	OIL FILTER KIT	MTU16V4000
1841	X52608100017	FUEL DELIVERY PUMP(E23523815)	MTU16V4000
1842	E23523815	FUEL DELIVERY PUMP(X52608100017)	MTU16V4000
1843	R5260701601	HP PUMP(r5260701601)	MTU16V4000
1844	EX52710100055	EXHAUST TURBOCHARGER(E0080965599)	MTU16V4000
1845	CX52710100055	CORE DEPOSIT TURBOCHARGER	MTU16V4000
1846	DDE05136306	CLAMP(05136306)	MTU16V4000
1847	05136306	CLAMP(DDE05136306)	MTU16V4000
1848	23540042	COVER ASM	MTU16V4000
1849	EX52420300001	COOLANT PUMP LT CIRCUIT(E23537087)	MTU16V4000
1850	E23537087	COOLANT PUMP LT CIRCUIT(EX52420300001)	MTU16V4000
1851	CX52420300001	CORE DEPOSIT WATER PUMP	MTU16V4000
1852	E23537086	COOLANT PUMP	MTU16V4000
1853	C23537086	CORE DEPOSIT WATER PUMP	MTU16V4000
1854	23524658	FAN CLTCH KT	MTU16V4000
1855	23540265	BELT GUARD	MTU16V4000
1856	E5241500850	ALTERNATOR	MTU16V4000
1857	C5241500850	CORE DEPOSIT GENERATOR	MTU16V4000
1858	DDE23514188	SEALANT GSKT(23514188)	MTU16V4000
1859	23514188	SEALANT GSKT(DDE23514188)	MTU16V4000
1860	X00025602	WIRING HARNESS TO INJECTOR	MTU1600/2000/4000
1861	X00E50700215	WIRING HARNESS FOR ON-ENGINE	MTU1600/2000/4000
1862	X00E50208056	CONNECTOR KIT	MTU1600/2000/4000
1863	X00E50207890	CONTROL UNIT	MTU1600/2000/4000
1864	X00E50205552/S0001	HOSING FOR ELECTRONICS(X00E50205552)	MTU1600/2000/4000
1865	X00E50205552	HOSING FOR ELECTRONICS(X00E50205552/S0001)	MTU1600/2000/4000
1866	X00E50205081	PRESSURE SENSOR	MTU1600/2000/4000
1867	X00E50700587	WIRING HARNESS FOR ON-ENGINE	MTU1600/2000/4000
1868	X00E50700568	WIRING HARNESS FOR ON-ENGINE	MTU1600/2000/4000
1869	X00E50204279	CONNECTING CABLE FOR ENGINE GOV	MTU1600/2000/4000
1870	X00E50201772	SPEED SENSOR	MTU1600/2000/4000
1871	X00E50205094	PRESSURE SENSOR	MTU1600/2000/4000
1872	X00041467	CABLE F/MONTRG SYST+GOV	MTU1600/2000/4000
1873	X00035262	CABLE FOR GOVERNOR	MTU1600/2000/4000
1874	X00E50200176	CONNECTION INTERFACE	MTU1600/2000/4000
1875	X00E50205148	PRESSURE SENSOR(0035352731)	MTU1600/2000/4000
1876	X00E50205292	TEMPERATURE SENSOR	MTU1600/2000/4000
1877	X00E50200003	CASSETTE	MTU1600/2000/4000

1878	X00005505	INDICATOR CONTAMINATION ADEC	MTU1600/2000/4000
1879	XP52699100134	O-RING	MTU4000
1880	X52499100020	GASKET	MTU4000
1881	X52499100021	GASKET	MTU4000
1882	0001426457	SEALING RING(1426457)	MTU4000
1883	1426457	SEALING RING(0001426457)	MTU4000
1884	0001426757	SEALING RING(1426757)	MTU4000
1885	1426757	SEALING RING(0001426757)	MTU4000
1886	0001426857	LAMELLAR RING	MTU4000
1887	X59514100001	GASKET	MTU4000
1888	007603050102	SEALING RING	MTU4000
1889	700429130000	O-RING	MTU16V4000
1890	5500780150	BUSHING	MTU12V4000G20
1891	5240180053	TUBE SLEEVE GUIDE	MTU12V4000G20
1892	5240150417	AXLE	MTU12V4000G20
1893	000472024000	RING SNAP	MTU12V4000G20
1894	8499970067	GASKET	MTU12V4000G20
1895	8690920051	GASKET	MTU12V4000G20
1896	X52418300026	CENTRIFUGAL OIL FLTR(5241800084)	MTU12V4000G20
1897	5241800084	CENTRIFUGAL OIL FLTR(X52418300026)	MTU12V4000G20
1898	8690920052	GASKET	MTU12V4000G20
1899	5272010006	GEAR(X00021750)	MTU12V4000G20
1900	23526490	BELT PULLEY	MTU12V4000G20
1901	DDE23511747	SEAL(23511747)	MTU12V4000G20
1902	23511747	SEAL(DDE23511747)	MTU12V4000G20
1903	5242061410	PULLEY CRANKSHAFT D420.00PL	MTU12V4000G20
1904	0022031575	REGUL INSERT	MTU16V4000
1905	X00018659	PRESSURE SENSOR	MTU16V4000
1906	X00E50204113	SPEED SENSOR	MTU16V4000
1907	X00E50201373	TEMPERATURE SENSOR	MTU16V4000
1908	0005358133	SPEED SENSOR	MTU16V4000
1909	X00E50201370	TEMPERATURE SENSOR	MTU16V4000
1910	X00E50203785	TEMPERATURE SENSOR	MTU16V4000
1911	X00E50203786	TEMPERATURE SENSOR	MTU16V4000
1912	X00E50200606	PRESSURE SENSOR	MTU16V4000
1913	X52418900009	GEAR PUMP FOR OIL MONITORNG	MTU16V4000
1914	E23535384	SHORTBLOCK 16V4000	MTU16V4000
1915	C23535384	CORE DEPOSIT SHORTBLOCK 16V4000	MTU16V4000
1916	E5240105720	CYLINDER HEAD	MTU16V4000
1917	C5240105720	CORE DEPOSIT CYL HEAD	MTU16V4000
1918	X00007157	FLANGE ASM	MTU16V4000
1919	5260300594	PTO FLANGE	MTU16V4000
1920	C0000352500	CORE DEPOSIT VIBRATION DAMPER	MTU16V4000
1921	DDE11501752	BOLT PHOS HEX(11501752)	MTU16V4000
1922	11501752	BOLT PHOS HEX(DDE11501752)	MTU16V4000
1923	DDE08929328	WASHER(08929328)	MTU16V4000
1924	08929328	WASHER(DDE08929328)	MTU16V4000
1925	5240500705	IDLER GEAR(X59305200001)	MTU16V4000
1926	200439016200	NUT ADEC(0000000000403)	MTU16V4000
1927	DDE23512307	ISOLATOR ECM MOUNT DDEC BLUE(23512307)	MTU16V4000
1928	53540784	SENSOR	MTU16V4000
1929	X00E50207205	PRESSURE SENSOR(0055353731)	MTU16V4000
1930	23524610	SENSOR(23540784)	MTU16V4000
1931	5240910224	LINK(X52408100002)	MTU16V4000

1932	8809900963	BANJO SCREW(700223004000)	MTU16V4000
1933	700223004000	BANJO SCREW(8809900963)	MTU16V4000
1934	E5260900014	NTERCOOLER(5260900014)	MTU16V4000
1935	5260900014	NTERCOOLER(E5260900014)	MTU16V4000
1936	C5260900014	CORE DEPOST CHARGE AIR COOLER	MTU16V4000
1937	X59399100084	ROBBER SLEEVE(X00023653)	MTU16V4000
1938	23540044	CAP PRESSURE EXPANSION TANK S2000	MTU16V4000
1939	23540759	CYLINDER HEAD COVER F/CRANKCASE (X52405500086	MTU16V4000
1940	DDE05104958	CLAMP(05104958)	MTU16V4000
1941	DDE05176400	BRACKET 90DEG(05176400)	MTU16V4000
1942	05176400	BRACKET 90DEG(DDE05176400)	MTU16V4000
1943	XP52799100607	V-BAND CLAMP(5240940042)	MTU16V4000
1944	5241420540	BRANCKET EXHAUST OUTLET	MTU16V4000
1945	EX52417200001	STARTER(X52417200001)	MTU16V4000
1946	CX52417200001	CORE DEPOSIT STARTER	MTU16V4000
1947	916016014201	CLAMP	MTU16V4000
1948	5241534640	BRACKET L H 30 SENSORE	MTU16V4000
1949	200625906327	BEARING BALL	MTU16V4000
1950	X52703500018	CARBON BRUSH(5271540014)	MTU16V4000
1951	20448	OBSERVATION WINDOW W/O INDICATOR	MTU16V4000
1952	205331	HEAT EXCHANGER PLATE SL-1 FUNKE FP 205-33-1	MTU16V4000L61
1953	4000043500	HEAT EXCHANGER GASKET SL-3 FUNKE DRAWING 400	MTU16V4000L61
1954	400043580	HEAT EXCHANGER GASKET SL-4 FUNKE DRAWING 400	MTU16V4000L61
1955	5240981140	FLANGE	MTU16V4000M70
1956	000933012040	BOLT HEX	MTU16V4000M70
1957	200835008006	STUD	MTU16V4000M70
1958	EX52710100051	EXHAUST TURBOCHARGER(X52710100051)	MTU16V4000M70
1959	X52710100051	EXHAUST TURBOCHARGER(EX52710100051)	MTU16V4000M70
1960	CX52710100051	CORE DEPOSIT TURBO CHARGER	MTU16V4000M70
1961	EX59420700008	SEAWATER PUMP(X59420700008)	MTU16V4000R43L
1962	X59420700008	SEAWATER PUMP(EX59420700008)	MTU16V4000R43L
1963	cx59420700008	CORE DEPOSIT WATER PUMP	MTU16V4000R43L
1964	000939012031	STUD	MTU16V4000R43L
1965	000000003184	HEX NUT	MTU16V4000R43L
1966	204017012015	HEX SCREW	MTU16V4000R43L
1967	000000002970	BOLT HEX ZNPH R5F	MTU16V4000R43L
1968	X59620200045	COOLANT ELBOW	MTU16V4000R43L
1969	70042917000	O-RING	MTU16V4000R43L
1970	000000003326	HEX SCREW	MTU16V4000R43L
1971	X00037441	COOLANT ELBOW	MTU16V4000R43L
1972	204017012009	HEX SCREW	MTU16V4000R43L
1973	5929975449	GASKET	MTU16V4000R43L
1974	X00037440	COOLANT ELBOW	MTU16V4000R43L
1975	X00037787	HALF-CLAMP	MTU16V4000R43L
1976	000000003437	BOLT HEX A3C	MTU16V4000R43L
1977	000908014002	PLUG	MTU16V4000R43L
1978	X00039742	PLUG-IN PIPE FOR SEAWATER	MTU16V4000R43L
1979	X00033976	SUPPORT FOR HEAT EXCHANGER	MTU16V4000R43L
1980	200433017000	WASHER	MTU16V4000R43L
1981	204014016010	HEX SCREW	MTU16V4000R43L
1982	204014016017	HEX SCREW	MTU16V4000R43L
1983	000000003719	HEX SCREW	MTU16V4000R43L
1984	000000001077	HEX SCREW	MTU16V4000R43L
1985	X59420500001	BASE PLATE	MTU16V4000R43L

1986	X59620200103	COVER PLATE FOR SEAWATER COO	MTU16V4000R43L
1987	X59520400008/87	PLATE-CORE HEAT EXCH FOR 16V	MTU16V4000R43L
1988	X00044862	SEALING RING	MTU16V4000R43L
1989	200939020000	STUD	MTU16V4000R43L
1990	X00041781	SPACER SLEEVE	MTU16V4000R43L
1991	735151016101	WASHER	MTU16V4000R43L
1992	204017016000	BOLT ZNPH R5F HEX	MTU16V4000R43L
1993	X00041755	GUIDE SPECIAL	MTU16V4000R43L
1994	X52820500001	SEALING RING FOR SEAWATER	MTU16V4000R43L
1995	X59608600002	VALVE FOR FUEL	MTU16V4000R43L
1996	735070010000	UNON	MTU16V4000R43L
1997	007603016103	RING GENERAL	MTU16V4000R43L
1998	735070016000	UNION	MTU16V4000R43L
1999	X00037445	COOLANT ELBOW	MTU16V4000R43L
2000	000000002088	HEX SCREW	MTU16V4000R43L
2001	204014012005	HEX SCREW	MTU16V4000R43L
2002	X59620800005	EXPANSION TANK	MTU16V4000R43L
2003	X59410100113	THREADED SLEEVE	MTU16V4000R43L
2004	X59420800019	INTERMEDIATE PLATE	MTU16V4000R43L
2005	X59420300036	DISTRIBUTOR	MTU16V4000R43L
2006	X59420800020	COOLANT LINE	MTU16V4000R43L
2007	700325028105	PIPE CLAMP HALF	MTU16V4000R43L
2008	000000001042	BOLT HEX A3C	MTU16V4000R43L
2009	700325028100	CLAMP HALF TUBE 1/1 D9-28	MTU16V4000R43L
2010	700325028200	CLAMP HALF TUBE 1/1 G8-28	MTU16V4000R43L
2011	304017008086	BOLT HEX A3C	MTU16V4000R43L
2012	X59520800013	COOLANT LINE	MTU16V4000R43L
2013	5242031540	BRACKET	MTU16V4000R43L
2014	000000003712	HEX SCREW	MTU16V4000R43L
2015	000000004745	HEX SCREW	MTU16V4000R43L
2016	X59420800008	RETAINER	MTU16V4000R43L
2017	X59520500001	SEAWATER ELBOW	MTU16V4000R43L
2018	5242030238	CLAMP HALF	MTU16V4000R43L
2019	735151012100	SPACER S2000/4000	MTU16V4000R43L
2020	000000001078	HEX SCREW	MTU16V4000R43L
2021	915007008008	CONNECTOR 8/6 F73	MTU16V4000R43L
2022	915005008003	CONE SEALING 10 F 73	MTU16V4000R43L
2023	915001008001	NUT	MTU16V4000R43L
2024	X59420500002	THREADED FLANGE FOR RAW WATER	MTU16V4000R43L
2025	5599920101	SPACER BUSHING	MTU16V4000R43L
2026	X00041623	ELBOWW	MTU16V4000R43L
2027	735189042001	SEALING CONE	MTU16V4000R43L
2028	915001040002	NUT 40 M52X1.5BL. GEOELT	MTU16V4000R43L
2029	700429210002	O-RING	MTU16V4000R43L
2030	00125010524	WASHER(000125010524)	MTU16V4000R43L
2031	000000001039	BOLT HEX A3C(000000001039)	MTU16V4000R43L
2032	000000001039	BOLT HEX A3C(000000001039)	MTU16V4000R43L
2033	X52820200173	THERMAL ACTUATOR	MTU16V4000R43L
2034	X52820600003	PLUG-IN PIPE FOR SEAWATER	MTU16V4000R43L
2035	5242030139	FLANGE	MTU16V4000R43L
2036	700429105000	O-RING	MTU16V4000R43L
2037	X52820200157	COOLANT ELBOW ON THERMOST HO	MTU16V4000R43L
2038	204014010007	HEX SCREW	MTU16V4000R43L
2039	X52820600005	PLUG-IN PIPE	MTU16V4000R43L

2040	X52820300003	FLANGE	MTU16V4000R43L
2041	00000001042	BOLT HEX A3C(000000001042)	MTU16V4000R43L
2042	X00035748	COOLANT ELBOW	MTU16V4000R43L
2043	00000003326	HEX SCREW(000000003326)	MTU16V4000R43L
2044	X59620600001	PLUG-IN PIPE	MTU16V4000R43L
2045	204017010021	BOLT A3C	MTU16V4000R43L
2046	X52820600004	PLUG-IN PIPE	MTU16V4000R43L
2047	X52820600002	PLUG-IN PIPE	MTU16V4000R43L
2048	X00029114	COOLANT ELBOW	MTU16V4000R43L
2049	000908030002	PLUG	MTU16V4000R43L
2050	EX00036684	COOLANT PUMP(X00036684)	MTU16V4000R43L
2051	X00036684	COOLANT PUMP(EX00036684)	MTU16V4000R43L
2052	CX00036684	CORE DEPOSIT WATER PUMP	MTU16V4000R43L
2053	000000003921	HEX SCREW	MTU16V4000R43L
2054	204017012019	HEX SCREW	MTU16V4000R43L
2055	000000003926	BOLT HEX A3C	MTU16V4000R43L
2056	000000004744	HEX NUT	MTU16V4000R43L
2057	X00038564	ELBOW	MTU16V4000R43L
2058	0049976736	VALVE DRAIN	MTU16V4000R43L
2059	X00043213	INJECTOR FOR ELBOW	MTU16V4000R43L
2060	915001032003	NUT	MTU16V4000R43L
2061	5242030340	SUPPORT MTG HOLDER	MTU16V4000R43L
2062	5281840309	ADAPTER CENTRIFUGAL OIL FILTER C23	MTU16V4000R43L
2063	000835012014	STUD	MTU16V4000R43L
2064	5281840609	FLANGE	MTU16V4000R43L
2065	5269970172	UNION	MTU16V4000R43L
2066	700429022003	O-RING	MTU16V4000R43L
2067	5281870008	TUBE SOCKET C23	MTU16V4000R43L
2068	X59318300009	SOCKET PIPE	MTU16V4000R43L
2069	735210027000	PLUG	MTU16V4000R43L
2070	23540432	FILTER 4 LITER CENTRIFUGAL SPINNER	MTU16V4000R43L
2071	X59401100038	INSPECT PORT COVER W/OIL FILTER(X59401100019)	MTU16V4000R43L
2072	X59401100019	INSPECT PORT COVER W/OIL FILTER(X59401100038)	MTU16V4000R43L
2073	8800180770	CONNECTOR THREADED	MTU16V4000R43L
2074	X00023282	OIL DIPSTICK(5240101672)	MTU16V4000R43L
2075	5240101672	OIL DIPSTICK(X00023282)	MTU16V4000R43L
2076	000000003021	HEX SCREW	MTU16V4000R43L
2077	X59601100009	INSPECT PORT COVER FOR SENSOR	MTU16V4000R43L
2078	X52718300010	OIL FILTER AUTOMATIC	MTU16V4000R43L
2079	000000000906	BOLT HEX A3C	MTU16V4000R43L
2080	204035016000	HEX NUT	MTU16V4000R43L
2081	5840700280	TUBE VENT W/BANJO FTG 8MM X 10MM	MTU16V4000R43L
2082	5069971416	BUSHING THREADED	MTU16V4000R43L
2083	000000003381	BOLT HEX A3C	MTU16V4000R43L
2084	5241802519	OIL LINE	MTU16V4000R43L
2085	700325018102	CLAMP HALF TUBE 1/2 D9-18	MTU16V4000R43L
2086	5241801219	TUBE OIL 635	MTU16V4000R43L
2087	5241800239	FLANGE	MTU16V4000R43L
2088	000000001464	BOLT HEX A3C	MTU16V4000R43L
2089	X52618200001	OIL LINE	MTU16V4000R43L
2090	X52418300002	OIL LINE(X00039766)	MTU16V4000R43L
2091	X00039766	OIL LINE(X52418300002)	MTU16V4000R43L
2092	5621532340	BRACKET H:77	MTU16V4000R43L
2093	700325022100	CLAMP HALF TUBE 1/1 D9-22	MTU16V4000R43L

2094	700327015000	GROMMET	MTU16V4000R43L
2095	5511532250	SPACER BUSHING	MTU16V4000R43L
2096	700325022200	CLAMP HALF TUBE 1/1 G8-22	MTU16V4000R43L
2097	0001812398	OIL EXTRACTION PUMP HAND S4000 S2000	MTU16V4000R43L
2098	0011809501	OIL PRELUBE PMP 3 PHASE 26 L/MIN	MTU16V4000R43L
2099	915003020202	BALL-TYPE UNION	MTU16V4000R43L
2100	915001020003	NUT	MTU16V4000R43L
2101	700419999002	UNION 20G 1 A	MTU16V4000R43L
2102	X00033303	DIRT TRAP	MTU16V4000R43L
2103	X00036967	FUEL PUMP	MTU16V4000R43L
2104	X00038367	FUEL FILTER	MTU16V4000R43L
2105	X00E50205261	GOVERNOR NOT ADJUSTED(X00E50205261/76)	MTU16V4000R43L
2106	5240510210	CAMSHAFT BEARING SIZE 1-0	MTU20V4000
2107	5289970045	O-RING	MTU20V4000
2108	000908014001	SCREW PLUG	MTU20V4000
2109	70042942000	O-RING	MTU20V4000
2110	700368045003	RUBBER SLEEVE	MTU20V4000
2111	700368050001	SLEEVE RUBBER	MTU20V4000
2112	X52818300016	MANIFOLD(5280100470)	MTU20V4000
2113	5280100470	MANIFOLD(X52818300016)	MTU20V4000
2114	5240332430	CRANKSHAFT BEARING AUX PTO END	MTU20V4000
2115	X52405200019	CAMSHAFT GEAR(X52403500004)	MTU20V4000
2116	X52403500004	CAMSHAFT GEAR(X52405200019)	MTU20V4000
2117	5280500101	CAMSHAFT	MTU20V4000
2118	5280520048	METERING WHEEL	MTU20V4000
2119	5240336601	BEARING MAIN/1-1/UP/	MTU20V4000
2120	000912008042	BOLT HEX	MTU20V4000
2121	5280300174	FLANGE	MTU20V4000
2122	700429557000	O-RING	MTU20V4000
2123	007603026106	SEALING RING	MTU20V4000
2124	8699970419	SEALING RING	MTU20V4000
2125	8699970418	SEALING RING	MTU20V4000
2126	8699970421	SEALING RING	MTU20V4000
2127	X52899100074	BUSHING(X00007341)	MTU20V4000
2128	X00007341	BUSHING(X52899100074)	MTU20V4000
2129	EX52803700010	PISTON(X00040842)	MTU20V4000
2130	X00040842	PISTON(EX52803700010)	MTU20V4000
2131	CX52803700010	CORE DEPOSIT PISTON	MTU20V4000
2132	CX00040057/42	CORE DEPOSIT CON ROD	MTU20V4000
2133	5240920012	RESTRICTOR	MTU20V4000
2134	735221009000	O-RING	MTU20V4000
2135	X00043004	HP FUEL LINE LEFT SIDE	MTU20V4000
2136	X52807700017	HP FUEL LINE RIGHT SIDE(X00043005)	MTU20V4000
2137	X00043005	HP FUEL LINE RIGHT SIDE(X52807700017)	MTU20V4000
2138	X52810100105	O-RING	MTU20V4000
2139	700429126001	O-RING	MTU20V4000
2140	X00016496	BEARING BUSHING	MTU20V4000
2141	5110251976	WASHER	MTU20V4000
2142	700429038002	O-RING	MTU20V4000
2143	700294042002	O-RING	MTU20V4000
2144	5110252510	BEARING	MTU20V4000
2145	X59599100058	WAHER(5110250052)	MTU20V4000
2146	8699970402	O-RING	MTU20V4000
2147	8699970403	O-RING	MTU20V4000

2148	700429200001	O-RING	MTU20V4000
2149	0289975248	O-RING	MTU20V4000
2150	5281420153	SLEEVE	MTU20V4000
2151	X52814500024	BELLOWS(5281400382)	MTU20V4000
2152	5281400382	BELLOWS(X52814500024)	MTU20V4000
2153	X00007118	V-BAND CLAMP	MTU20V4000
2154	0249978447	SEALING RING	MTU20V4000
2155	700429057001	O-RING	MTU20V4000
2156	EX52803200003	FLYWHEEL(X52803200003)	MTU20V4000
2157	X52803200003	FLYWHEEL(EX52803200003)	MTU20V4000
2158	CX52803200003	CORE DEPOSIT FLYWHEEL	MTU20V4000
2159	304014010015	BOLT HEX	MTU20V4000
2160	X00007179	GAGE ASM OIL LEVEL	MTU20V4000
2161	700223006000	BOLT BANJO A8 S2000/4000	MTU20V4000
2162	XP52700600008	MAINTENANCE KIT	MTU20V4000
2163	X00003329	PROTECTIVE GRILL	MTU20V4000
2164	8691840034	FILTERING SCREW	MTU20V4000
2165	X00E50201395	DIFF-PRESS MONITOR	MTU20V4000
2166	X00004931	GROOVED BALL BEARING	MTU20V4000
2167	X00005746	GROOVED BALL BEARING	MTU20V4000
2168	23540455	CENTRIFUGAL OIL FILTER ASM	MTU20V4000
2169	23540471	SEALS KIT	MTU20V4000
2170	23540469	BAND CLAMP	MTU20V4000
2171	23540460	CIRCLIP KIT	MTU20V4000
2172	700223010000	BOLT BANJO A12	MTU20V4000
2173	CX52620200081	CORE DEPOSIT WATER PUMP	MTU20V4000
2174	735038008113	HOSE	MTU20V4000
2175	735038008109	HOSE	MTU20V4000
2176	916016020202	CLAMP	MTU20V4000
2177	007603060101	SEALING RING	MTU20V4000
2178	007603016104	SEALING RING	MTU20V4000
2179	007603064100	WASHER A COP	MTU20V4000
2180	5591530550	SPACER BUSHING	MTU20V4000
2181	735038012111	HOSE	MTU20V4000
2182	5241800919	HOSE ASM+3 FC234	MTU20V4000
2183	5242000282	HOSE	MTU20V4000
2184	735038025106	HOSE	MTU20V4000
2185	0009930795	BELT POLY-V 2.36W 118LG	MTU20V4000
2186	23504352	SEAL RING(5319972045)	MTU20V4000
2187	03037871	CLUTCH O/H	MTU20V4000
2188	5285400097	SOLENOID VALVE	MTU20V4000
2189	X00012033	CONNECTING CABLE FOR FAN DRIVE	MTU20V4000
2190	0002370911	ISOLATOR MT	MTU20V4000
2191	735211015000	UNION	MTU20V4000
2192	700160000013	ELBOW 90 DEG KR 12-MV	MTU20V4000
2193	5319973772	FITTING	MTU20V4000
2194	5319975572	FITTING	MTU20V4000
2195	5244860524	FITTING	MTU20V4000
2196	X52802600012	DRIVE F/AIR CONDIT COMPR	MTU20V4000
2197	X00032291	WIRING HARNESS FOR ON-ENGINE	MTU20V4000
2198	X00012025	WIRING HARNESS FOR ON-ENGINE	MTU20V4000
2199	X00012021	WIRING HARNESS TO INJECTOR	MTU20V4000
2200	0005338443	PIPE	MTU20V4000
2201	0005358433	SPEED SENSOR	MTU20V4000

2202	0035352331	PRESSURE SENSOR	MTU20V4000
2203	EX52421300008	ALTERNATOR(5241500450)	MTU20V4000
2204	CX52421300008	CORE DEPOSIT GENERATOR	MTU20V4000
2205	000933012120	BOLT HEX	MTU20V4000
2206	X59402600018	RETAINER(5241550627)	MTU20V4000
2207	5241550627	RETAINER(X59402600018)	MTU20V4000
2208	X59402800027	PROTECTIVE COVER(23540905)	MTU20V4000
2209	23540905	PROTECTIVE COVER(X59402800027)	MTU20V4000
2210	000933010116	BOLT HEX	MTU20V4000
2211	007349010001	WASHER	MTU20V4000
2212	X00021704	BRACKET ALT SUPT	MTU20V4000
2213	000931012052	BOLT HEX	MTU20V4000
2214	735151010101	SPACER A10.5 A3C	MTU20V4000
2215	X00022214	RETAINER	MTU20V4000
2216	000931016083	HEX SCREW	MTU20V4000
2217	735151016100	SPACER	MTU20V4000
2218	5280780041	RETAINER	MTU20V4000
2219	700325022115	PIPE HALF-CLAMP	MTU20V4000
2220	700325022114	CLAMP HALF TUBE 1/1 D11-22	MTU20V4000
2221	735151008200	SPACER	MTU20V4000
2222	700325015110	CLAMP HALF TUBE 1/1 D11-15	MTU20V4000
2223	x00018512	RETAINER	MTU20V4000
2224	X52810100137	O-RING	MTU20V4000
2225	000N15140/1	DISC-PACK ELEMENT	MTU183-4000
2226	700429045001	O-RING	MTU4000
2227	700429185002	O-RING	MTU4000
2228	700429340000	O-RING	MTU4000
2229	X00032629	O-RING	MTU4000
2230	XP52611400046	O-RING	MTU4000
2231	XP52707700006	O-RING	MTU4000
2232	XP52707700007	O-RING	MTU4000
2233	XP52707700008	O-RING	MTU4000
2234	XP52707700010	O-RING	MTU4000
2235	XP52407700038	O-RING	MTU4000
2236	XP52707700015	O-RING	MTU4000
2237	700429300000	O-RING	MTU4000
2238	700429007001	O-RING	MTU4000
2239	C5240301120/42	42	MTU12V4000G20
2240	0001843097	CENTRIFUGAL OIL FLTR(X52418300026)	MTU12V4000G20
2241	X52404500009	SPARK PLUG	MTU16V4000L62
2242	X00014733	FILTER ELEMENT	MTU16V4000L62
2243	5351580003	IGNITION COIL W/SUPPORT	MTU16V4000L62
2244	X00003469	SENSOR	MTU16V4000L62
2245	5351530120	SENSOR(X00E50207476)	MTU16V4000L62
2246	X00E50207476	SENSOR(5351530120)	MTU16V4000L62
2247	X00028707	RUBBER CAP	MTU16V4000L62
2248	X00021364	TEMP SENSOR(X00E50203325)	MTU16V4000L62
2249	X00E50203325	TEMP SENSOR(X00021364)	MTU16V4000L62
2250	5240550701	INLET ROCKER ARM(5240500433)	MTU16V4000L62
2251	5240550203	EXHAUST ROCKER ARM(5240500434)	MTU16V4000L62
2252	5240550705	ROCKER SHAFT(5240500436)	MTU16V4000L62
2253	000000003323	SCREW	MTU16V4000L62
2254	X59403700007	PISTON(EX59403700005)	MTU12V4000G63
2255	X59618300028/87	OIL COOLER(X59618300002/87)	MTU4000

2256	X59618300002/87	OIL COOLER(X59618300028/87)	MTU4000
2257	EX52617300006	STARTER(X52617300006)	MTU4000
2258	X52617300006	STARTER(EX52617300006)	MTU4000
2259	CX52617300006	CORE DEPOSIT ATARTER	MTU4000
2260	X52605100017	CAMSHAFT FOR 12V(5260500001)	MTU4000
2261	5260500001	CAMSHAFT FOR 12V(X52605100017)	MTU4000
2262	5240550018	ROLLER TAPPET(5240540101)	MTU4000